




Count on it.

Operator's Manual

Greensmaster® Flex™ 1820/2120 Traction Unit

Model No. 04044—Serial No. 400000000 and Up

Model No. 04045—Serial No. 400000000 and Up



G032415



This product complies with all relevant European directives; for details, please see the separate product specific Declaration of Conformity (DOC) sheet.

⚠ WARNING

CALIFORNIA Proposition 65 Warning

This product contains a chemical or chemicals known to the State of California to cause cancer, birth defects, or reproductive harm.

The engine exhaust from this product contains chemicals known to the State of California to cause cancer, birth defects, or other reproductive harm.

It is a violation of California Public Resource Code Section 4442 or 4443 to use or operate the engine on any forest-covered, brush-covered, or grass-covered land unless the engine is equipped with a spark arrester, as defined in Section 4442, maintained in effective working order or the engine is constructed, equipped, and maintained for the prevention of fire.

This spark ignition system complies with Canadian ICES-002.

Operating this machine between 1,524 to 2,438 m (5,000 to 8,000 ft) above sea level requires the high-altitude kit. See your Authorized Toro Dealer.

Introduction

This machine is a walk-behind, reel-blade lawn mower intended to be used by professional, hired operators in commercial applications. It is primarily designed for cutting grass on well-maintained lawns in parks, golf courses, sports fields, and on commercial grounds. It is not designed for cutting brush, mowing grass and other growth alongside highways, or for agricultural uses.

Read this information carefully to learn how to operate and maintain your product properly and to avoid injury and product damage. You are responsible for operating the product properly and safely.

You may contact Toro directly at www.Toro.com for product safety and operation training materials, accessory information, help finding a dealer, or to register your product.

Whenever you need service, genuine Toro parts, or additional information, contact an Authorized Service Dealer or Toro Customer Service and have the model

and serial numbers of your product ready. Figure 1 identifies the location of the model and serial numbers on the product. Write the numbers in the space provided.




Figure 1

1. Location of the model and serial numbers

Model No. _____

Serial No. _____

This manual identifies potential hazards and has safety messages identified by the safety-alert symbol (Figure 2), which signals a hazard that may cause serious injury or death if you do not follow the recommended precautions.



Figure 2

1. Safety-alert symbol.

This manual uses 2 words to highlight information. **Important** calls attention to special mechanical information and **Note** emphasizes general information worthy of special attention.

Contents

Safety	4
General Safety	4
Preparation	4
Operation	4
Maintenance and Storage	5
Hauling	5
Toro Mower Safety	5
Safety and Instructional Decals	6
Setup	8
1 Preparing the Traction Unit	9
2 Installing the Cutting Unit to the Traction Unit	9
3 Installing the Handle Retainers	10
4 Installing the Transport Wheels	10
5 Checking the Engine-Oil Level	11
6 Installing the Grass Basket	11
Product Overview	13
Controls	13
Specifications	17
Attachments/Accessories	17
Operation	17
Think Safety First	17
Checking the Engine-Oil Level	17
Filling the Fuel Tank	17
Adjusting the Handle Height	19
Adjusting the Handle Angle	19
Adjusting the Throttle Control	19
Starting the Engine	20
Shutting Off the Engine	20
Transporting the Machine	20
Preparing to Mow	20
Mowing Tips	21
Checking the Operation of the Interlock Switches	22
Releasing the Transmission	23
Setting the Machine to Match Turf Conditions	24
Maintenance	25
Recommended Maintenance Schedule(s)	25
Daily Maintenance Checklist	26
Engine Maintenance	27
Servicing the Engine Oil	27
Servicing the Air Cleaner	28
Servicing the Spark Plug	29
Fuel System Maintenance	29
Cleaning the Fuel-Tank Screen	29
Replacing the Fuel Line	29
Electrical System Maintenance	30
Servicing the Traction Interlock Switch	30
Servicing the Brake-Interlock Switch	30
Brake Maintenance	31
Adjusting the Service/Parking Brake	31
Belt Maintenance	31
Inspecting the Reel-Drive Belt	31
Visually Inspecting the Reel Clutch	32

Engaging/Disengaging the Transmission-Belt Tensioner	32
Controls System Maintenance	33
Adjusting the Traction Control	33
Adjusting the Reel Control	33
Storage	34

Safety

This machine has been designed in accordance with EN ISO 5395:2013 and ANSI B71.4-2012.

General Safety

This product is capable of amputating hands and feet and of throwing objects. Always follow all safety instructions to avoid serious personal injury.

Using this product for purposes other than its intended use could prove dangerous to you and bystanders.

- Read and understand the contents of this *Operator's Manual* before starting the engine.
- Do not put your hands or feet near moving components of the machine.
- Do not operate the machine without all guards and other safety protective devices in place and working on the machine.
- Keep clear of any discharge opening. Keep bystanders and pets a safe distance away from the machine.
- Keep children out of the operating area. Never allow children to operate the machine.
- Stop the machine and shut off the engine before servicing, fueling, or unclogging the machine.

Improperly using or maintaining this machine can result in injury. To reduce the potential for injury, comply with these safety instructions and always pay attention to the safety-alert symbol, which means Caution, Warning, or Danger—personal safety instruction. Failure to comply with these instructions may result in personal injury or death.

Preparation

- Wear appropriate clothing, including eye protection; slip-resistant, substantial footwear; and hearing protection. Tie back long hair, secure loose clothing, and do not wear jewelry.
- Inspect the area where you will use the machine and remove all objects that the machine could throw.
- Replace faulty silencers.
- Evaluate the terrain to determine what accessories and attachments are needed to properly and safely perform the job.
- Use accessories and attachments approved by The Toro® Company only.
- Check that operator's presence controls, safety switches, and shields are attached and functioning properly.

Operation

- Do not operate the engine in a confined space where dangerous carbon monoxide and other exhaust gasses can collect.
- Operate the machine only in good visibility and appropriate weather conditions. Do not operate the machine when there is the risk of lightning.
- Before attempting to start the engine, disengage all blade attachment clutches, shift into neutral, and engage the parking brake.
- Watch for holes, ruts, bumps, rocks, or other hidden objects. Uneven terrain could cause a slip-and-fall accident.
- Watch out for traffic when crossing or near roadways.
- Stop the blades rotating before crossing surfaces other than grass.
- Do not change the engine governor settings or overspeed the engine. Operating the engine at excessive speed may increase the hazard of personal injury.
- Shut off the engine and disengage the drive to the attachment:
 - Before leaving the operator's position
 - Before refuelling
 - Before removing the grass basket
 - Before making height adjustment unless adjustment can be made from the operator's position
 - Before clearing blockages
 - Before checking, cleaning, or working on the machine
 - After striking a foreign object or if an abnormal vibration occurs. Inspect the machine for damage and make repairs before restarting and operating the equipment.

Disengage drive to attachments when transporting or not in use.

- Reduce the throttle setting before shutting off the engine and, if the engine is provided with a fuel shut-off valve, turn the valve off at the conclusion of mowing.
- Slow down and use caution when making turns and crossing roads and sidewalks. Stop the reels when not mowing.
- Do not operate the machine if you are ill, tired, or under the influence of alcohol or drugs.
- Use extreme care when approaching blind corners, shrubs, trees, or other objects that may block your view.

Maintenance and Storage

- Keep all nuts, bolts, and screws tight to be sure the equipment is in safe working condition.
- Never store the machine or fuel container where there is an open flame, spark, or pilot light, such as on a water heater or on other appliances.
- Allow the engine to cool before storing the machine in any enclosure.
- Check the grass catcher components frequently and replace them with the manufacturer's recommended parts when necessary.
- Keep all parts in good working condition and all hardware and hydraulic fittings tightened. Replace all worn or damaged parts and decals.
- If the fuel tank has to be drained, do this outdoors.
- Tipping the machine may cause the fuel to leak. If fuel comes in contact with the fuel cap, replace the cap. Fuel is flammable and explosive, and can cause personal injury. Run the engine dry to remove the fuel with a hand pump; never siphon the fuel.
- Be careful during adjustment of the machine to prevent entrapment of the fingers between moving blades and fixed parts of the machine.
- Disengage drives, disengage the cutting unit, set the parking brake, shut off the engine, and disconnect the spark plug wire. Wait for all movement to stop before adjusting, cleaning, or repairing.
- Clean grass and debris from the cutting unit, drives, mufflers, cooling screens, and the engine to help prevent fires. Clean up oil or fuel spills.
- Carefully release pressure from components with stored energy.
- Disconnect the battery and remove the spark plug wire before making any repairs. Disconnect the negative terminal first and the positive last. Connect the positive first and negative last.
- Use care when checking the reel. Wear gloves and use caution when servicing them.

Hauling

- Use care when loading or unloading the machine.
- Secure the machine from rolling.

Toro Mower Safety

- Know how to shut off the engine quickly.
- Handle fuel carefully. Wipe up any spills.
- Always stand behind the handle when starting and operating the machine.
- When near or crossing roads, always yield the right-of-way.
- The grass basket must be in place, during the mowing operation, for maximum safety. Shut the engine off before emptying the basket.
- Do not touch the engine, muffler, or exhaust pipe while the engine is running or soon after it has shut off because these areas could be hot enough to cause burns.

Maintenance and Storage

- Check all fuel lines for tightness and wear on a regular basis. Tighten or repair them as needed.
- If the engine must be running to perform a maintenance adjustment, keep hands, feet, clothing, and any parts of the body away from the cutting unit, attachments and any moving parts. Keep everyone away.
- To ensure safety and accuracy, have an Authorized Toro Distributor check the maximum engine speed with a tachometer. The maximum governed engine speed should be between 3,190 and 3,340 rpm.
- If major repairs are ever needed or if assistance is desired, contact an Authorized Toro Distributor.
- To ensure optimum performance and continued safety certification of the machine, use only genuine Toro replacement parts and accessories. Replacement parts and accessories made by other manufacturers could be dangerous, and such use could void the product warranty.

Safety and Instructional Decals




Safety decals and instructions are easily visible to the operator and are located near any area of potential danger. Replace any decal that is damaged or missing.

CALIFORNIA SPARK ARRESTER WARNING

Operation of this equipment may create sparks that can start fires around dry vegetation. A spark arrester may be required. The operator should contact local fire agencies for laws or regulations relating to fire prevention requirements. 117-2718

decal117-2718


117-2718



decal130-8322

130-8322


1. Use only gasoline that contains 10% ethanol by volume (E10) or less.
2. Read the *Operator's Manual*.
3. Do not use gasoline that contains more than 10% ethanol by volume (E10).



decal120-9598

120-9598

1. Brake
2. Release handle to disengage the brake.
3. Compress the handle to engage the brake.
4. Parking brake
5. Rotate the latch to lock the parking brake; compress the handle to release the latch.



decal120-9571

120-9571


1. Lower the lever to disengage the traction.



decal120-9570

120-9570


1. Warning—stay away from moving parts, keep all guards and shields in place.



decal131-3111

131-3111


1. Fast
2. Slow



decal120-2769

120-2769

1. Toxic gas inhalation hazard—do not operate indoors.
2. Explosion hazard—shut off the engine and keep away from open flames when refueling.
3. Warning—shut off the engine and turn off the fuel before leaving the machine.
4. Warning—disconnect the spark-plug wire and read the instruction before servicing or performing maintenance.
5. Hot surface/burn hazard—do not touch hot surfaces.
6. Warning—read the *Operator's Manual*; when adding fuel to the tank, only fill to the bottom of the fill tube.



decal115-7271

115-7271


1. Engage the reel.
2. Engage the lever.
3. Disengage the reel.
4. Disengage the lever.



decal133-2335

133-2335

1. Warning—read the *Operator's Manual*; do not operate the machine unless you are trained.
2. Warning—wear hearing protection.
3. Thrown object hazard—keep bystanders a safe distance away from the machine.
4. Warning—stay away from moving parts; keep all guards and shields in place.
5. Do not tow the machine.



decal115-7274

115-7274

1. Lights (optional)
2. Hour meter
3. Engine—start
4. Engine—shut off

Setup

Loose Parts

Use the chart below to verify that all parts have been shipped.

Procedure	Description	Qty.	Use
1	No parts required	–	Prepare the traction unit (optional).
2	Bolt (3/8 x 3/4 inch)	2	Install the cutting unit to the traction unit.
3	Handle retainer	2	Install the handle retainers.
	Hairpin cotter	2	
4	Transport wheels—Optional Transport Wheel Kit (Model 04123)	2	Install the transport wheels.
5	No parts required	–	Check the engine-oil level.
6	Grass basket	1	Install the grass basket.

Media and Additional Parts

Description	Qty.	Use
Operator's Manual	1	Read or view these materials before operating the machine.
Engine operator's manual	1	
Parts Catalog	1	
Operator training material	1	
Certificate of Compliance	1	

Note: Determine the left and right sides of the machine from the normal operating position.

1

Preparing the Traction Unit

Optional

No Parts Required

Procedure

If you are installing cutting unit Models 04251, 02452, 04253, or 04254 on this traction unit, complete the following steps:

1. Position the cutting unit on a flat, level surface.
2. On both pitch arms (Figure 3), measure 2 mm (0.09 inch) in on the tabs and grind down the corner as shown in Figure 4.




Figure 3

1. Pitch arms




Figure 4

3. Paint the revealed metal to prevent corrosion.

2

Installing the Cutting Unit to the Traction Unit

Parts needed for this procedure:

2	Bolt (3/8 x 3/4 inch)
---	-----------------------

Procedure

1. Place the machine on its drums on a level surface.
2. Lower the kickstand and push in the locking pin to lock the kickstand in the service position (Figure 5). Allow the machine to rest on the locking pin.




Figure 5

1. Kickstand—storage position
2. Locking pin
3. Kickstand—service position

3. Push the cutting unit under the traction unit and to the left to engage the transmission coupling (Figure 6).

3

Installing the Handle Retainers

Parts needed for this procedure:

2	Handle retainer
2	Hairpin cotter

Procedure

1. While supporting the handle, remove the cable ties securing the handle clamps to the side plates (Figure 8).





Figure 8

1. Hairpin cotter
2. Handle retainer

2. Pivot the handle to the desired operating position, insert a handle retainer over the handle clamp and into the matching holes in the side plate (Figure 8).
3. Secure the clamp in position with a hairpin cotter (Figure 8).
4. Repeat the procedure on the opposite side of the handle.
5. Adjust the handle height to the desired position; refer to [Adjusting the Handle Height \(page 19\)](#).

Note: The machine is shipped with the handle adjusted to the lowest position. The machine is traditionally operated with the handle telescoped out to its maximum height.




G000483

g000483

Figure 6

1. Transmission coupling

4. Maneuver the traction unit frame (Figure 7) forward until it engages the cutting unit pivot arms.



G032418

g032418

Figure 7

1. Cutting unit pivot arms
2. Traction unit frame
3. Bolts

5. Secure the traction unit frame to the cutting unit pivot arms with 2 bolts (3/8 x 3/4 inch) (Figure 7).

Note: To remove the cutting unit, just loosen the 2 bolts (3/8 x 3/4 inch) approximately 1-1/2 turns and rotate the pivot arms out.

6. Push down on the kickstand to release the spring-loaded locking pin and allow the kickstand to rotate up to the storage position.

4

Installing the Transport Wheels

Parts needed for this procedure:

2	Transport wheels—Optional Transport Wheel Kit (Model 04123)
---	---

Procedure

1. Push the kickstand down with your foot **in the center of the kickstand** and pull up on the lower center machine handle until the kickstand has rotated forward, over center ([Figure 9](#)).




Figure 9

1. Kickstand

2. Press the wheel locking clip toward the center of wheel and slide the wheel onto the hex shaft ([Figure 10](#)).




Figure 10

1. Locking clip

3. Rotate the wheel back and forth until it slides completely onto the axle and the locking clip is secured in the groove on the axle shaft.
4. Repeat the procedure on the opposite side of the machine.
5. Inflate the tires to 83 to 103 kPa (12 to 15 psi).
6. Carefully lower the machine off the kickstand by pushing forward slowly or by lifting the lower center handle support, allowing the kickstand to spring back to its normal position.

5

Checking the Engine-Oil Level

No Parts Required

Procedure

Check the engine-oil level; refer to [Checking the Engine-Oil Level \(page 27\)](#).

6

Installing the Grass Basket

Parts needed for this procedure:

1	Grass basket
---	--------------

Procedure

1. Grasp the basket by the handle (Figure 11).




Figure 11

1. Basket hooks

2. Guide the basket lip between the cutting unit side plates and over the front roller (Figure 11).
3. Install the basket hooks over the frame loop (Figure 11).

Important: If you ever drop the basket, examine the pitch arm contact points near the lower lip of the basket for damage (Figure 12). Straighten them before using the basket. Using the basket with bent pitch arm contact points may cause contact between the basket and reel causing undesired noise and/or damage to the basket and reel.




Figure 12

1. Pitch arm contact point

Product Overview




Figure 13

- | | |
|---|-------------------------|
| 1. Traction and reel-drive engagement lever | 6. Fuel tank |
| 2. Operator-presence control | 7. Grass basket |
| 3. Handle | 8. Cutting unit |
| 4. Service brake | 9. Transport wheel axle |
| 5. Control panel | |

Throttle Control

The throttle control (Figure 14 and Figure 15) is located on the right, rear side of the control panel. Rotate the throttle to regulate the engine speed.




Figure 15

- | | |
|---------------|---------------|
| 1. Full speed | 2. Slow speed |
|---------------|---------------|

Controls




Figure 14

- | | |
|-----------------------------------|---|
| 1. Open space for optional lights | 5. Operator-presence control |
| 2. Parking-brake latch | 6. On/off switch |
| 3. Service brake | 7. Throttle control |
| 4. Handle | 8. Traction and reel-drive engagement lever |

Traction and Reel-Drive Engagement Lever

The traction and reel-drive engagement lever (Figure 16) is located on the front right side of the control panel. For transport operation, the lever has 2 positions: NEUTRAL and FORWARD. Pushing the lever forward engages the traction drive.

Note: To move the lever, you must first engage the operator-presence control.




Figure 16

- | | |
|--|--|
| 1. NEUTRAL | 3. Traction drive-engaged (transport) |
| 2. Traction drive neutral and reel drive off | 4. Traction drive and reel drive engaged |

For reel operation, the lever has 2 positions: ENGAGE and DISENGAGE. Move the top of the lever to the left then forward to engage the reel and begin mowing. Push the lever to the right to disengage the reel and continue forward motion or pull back on it to disengage both the reel and the traction drive.

Note: If you release the operator-presence control, the lever returns to neutral and the machine stops.

Service Brake

The service brake ([Figure 17](#)) is located on the left front side of the handle. Pulling the lever back engages the service brake. You must disengage the brake before you engage the traction drive.




Figure 17

- | | |
|------------------------|------------------|
| 1. Parking-brake latch | 2. Service brake |
|------------------------|------------------|

Parking-Brake Latch

The parking-brake latch ([Figure 17](#)) is used with the service brake. With the service brake engaged, rotate the parking-brake latch toward the brake handle and disengage the service brake onto the latch to hold the service brake in place. Pull the brake lever to release it.

On/Off Switch

The On/Off switch ([Figure 14](#)) is located on top of the control panel. Move the switch to the ON position to start the engine and OFF to shut off the engine.

Operator-Presence Control (OPC)

You must engage the operator-presence control ([Figure 14](#)) before engaging the traction lever. Releasing the OPC during operation returns the machine to neutral but does not shut off the engine.

Choke Lever

The choke lever (Figure 18) is located on the engine. The lever has 2 positions: RUN and CHOKE. Move the choke lever to the half-open position when starting a cold engine. After the engine starts, move the lever to the RUN position.




Figure 18

1. Choke lever in the CHOKE position

Fuel-Shutoff Valve

The fuel-shutoff valve (Figure 19) is located on the engine. The valve has 2 positions: CLOSED and OPEN. Move the lever to the CLOSED position when storing or transporting machine. Open the valve before starting the engine.




Figure 19

1. Fuel-shutoff valve in closed position

Recoil-Starter Handle

Pull the recoil-starter handle (Figure 20) to start the engine.




Figure 20

1. Recoil-starter handle

Kickstand

The kickstand (Figure 22) is mounted to the rear of the machine and is used to raise the rear of the machine for installing or removing the transport wheels and for preventing the machine for falling onto the handle when you remove the reel.

- To use the kickstand to install the transport wheels, lower it to the ground and step down on the kickstand loop while pulling up and back on the lower center machine handle (Figure 21).

⚠ CAUTION

The machine is heavy and can cause back strain if lifted improperly.

Put foot pressure down only on the kickstand loop and only use the lower center machine handle to raise the machine. Attempting to raise the machine onto the kickstand any other way can cause injury.




Figure 21

1. Lower center machine handle
2. Kickstand loop




Figure 22

1. Kickstand
2. Kickstand loop




Figure 23

1. Kickstand—STORAGE position
2. Locking pin
3. Kickstand—SERVICE position

- To prevent the unit from tipping backward when removing the reel, lower the kickstand and push in the locking pin to lock it in the SERVICE position (Figure 23).

Specifications

1820 Traction Unit

Width	82.5 cm (32-1/2 inches)
Height	104.8 cm (41-1/4 inches)
Length with basket	152.4 cm (60 inches)
Net Weight (with 11 blade cutting unit and grass basket installed)	117 kg (258 lb)
Width of cut	46 cm (18 inches)
Height of cut	1.5 to 7.5 mm (1/16 to 19/64 inches) with Micro-Cut bedknife
Clip frequency	Adjustable (refer to cutting unit Operator's Manual)

2120 Traction Unit

Width	90.1 cm (35-1/2 inches)
Height	104.8 cm (41-1/4 inches)
Length with basket	152.4 cm (60 inches)
Net Weight (with 11 blade cutting unit and grass basket installed)	117.9 kg (260 lb)
Width of cut	53.3 cm (21 inches)
Height of cut	1.5 to 7.5 mm (1/16 to 19/64 inches) with Micro-Cut bedknife
Clip frequency	Adjustable (refer to Cutting Unit Operator's Manual)

Attachments/Accessories

A selection of Toro approved attachments and accessories is available for use with the machine to enhance and expand its capabilities. Contact your Authorized Service Dealer or Distributor or go to www.Toro.com for a list of all approved attachments and accessories.

To best protect your investment and maintain optimal performance of your Toro equipment, count on Toro genuine parts. When it comes to reliability, Toro delivers replacement parts designed to the exact engineering specification of our equipment. For peace of mind, insist on Toro genuine parts.

Operation

Note: Determine the left and right sides of the machine from the normal operating position.

Think Safety First

Carefully read all safety instructions and symbols in the safety section. Knowing this information could help you or bystanders avoid injury.

⚠ CAUTION

This machine produces sound levels that can cause hearing loss through extended periods of exposure.

Wear hearing protection when operating this machine.




Figure 24

1. Wear eye protection.
2. Wear hearing protection.

Checking the Engine-Oil Level

Check the engine-oil level before each use or every 8 operating hours, refer to [Checking the Engine-Oil Level \(page 27\)](#).

Filling the Fuel Tank

The fuel tank capacity is 3.0 L (0.79 US gallons).

- For best results, use only clean, fresh (less than 30 days old), unleaded gasoline with an octane rating of 87 or higher ((R+M)/2 rating method).
- Ethanol:** Gasoline with up to 10% ethanol (gasohol) or 15% MTBE (methyl tertiary butyl ether) by volume is acceptable. Ethanol and MTBE are not the same. Gasoline with 15% ethanol (E15) by volume is not approved for use. **Never use gasoline that contains more than 10% ethanol by volume**, such as E15 (contains 15% ethanol), E20 (contains 20% ethanol), or E85 (contains up to 85% ethanol). Using unapproved gasoline may cause performance problems and/or engine damage which may not be covered under warranty.

- **Do not** use gasoline containing methanol.
- **Do not** store fuel either in the fuel tank or fuel containers over the winter unless a fuel stabilizer is used.
- **Do not** add oil to gasoline.

⚠ DANGER

In certain conditions, fuel is extremely flammable and highly explosive. A fire or explosion from fuel can burn you and others and can damage property.

- Fill the fuel tank outdoors, in an open area, when the engine is cold. Wipe up any fuel that spills.
- Never fill the fuel tank inside an enclosed trailer.
- Do not fill the fuel tank completely full. Add fuel to the fuel tank until the level is 6 to 13 mm (1/4 to 1/2 inch) below the bottom of the filler neck. This empty space in the tank allows fuel to expand.
- Never smoke when handling fuel, and stay away from an open flame or where fuel fumes may be ignited by a spark.
- Store fuel in an approved container and keep it out of the reach of children. Never buy more than a 30-day supply of fuel.
- Do not operate without entire exhaust system in place and in proper working condition.

⚠ DANGER

In certain conditions during fueling, static electricity can be released, causing a spark which can ignite the fuel vapors. A fire or explosion from fuel can burn you and others and can damage property.

- Always place fuel containers on the ground away from your vehicle before filling.
- Do not fill fuel containers inside a vehicle or on a truck or trailer bed because interior carpets or plastic truck-bed liners may insulate the container and slow the loss of any static charge.
- When practical, remove equipment from the truck or trailer and fuel it on the ground. If this is not possible, then fuel such equipment with a portable container rather than from a fuel-dispenser nozzle.
- If you must use a fuel-dispenser nozzle, keep the nozzle in contact with the rim of the fuel tank or container opening at all times until fueling is complete.

⚠ WARNING

Fuel is harmful or fatal if swallowed. Long-term exposure to vapors can cause serious injury and illness.

- Avoid prolonged breathing of vapors.
 - Keep your face away from the nozzle and fuel tank or conditioner bottle opening.
 - Avoid contact with skin; wash off spills with soap and water.
1. Clean around the fuel-tank cap and remove the cap from the tank ([Figure 25](#)). Fill the fuel tank no higher than to the bottom of the filter screen. Do not overfill.




Figure 25

1. Fuel-tank cap

2. Install the fuel-tank cap and wipe up any spilled fuel.

Adjusting the Handle Height

Note: The machine is shipped with the handle adjusted to the lowest position. The machine is normally operated with the handle telescoped out to its maximum height.

1. Loosen the 3 carriage bolts and nuts securing each side of the handle in the handle clamps (Figure 26).




Figure 26

1. Handle clamp
2. Nut
3. Carriage bolts

2. Pull up on the handle slowly and evenly on each side until it is in the desired operating position.
3. Tighten the carriage bolts and nuts to lock the adjustment.

Adjusting the Handle Angle

1. Remove the hairpin cotters from the handle retainers on each side of the machine (Figure 27).




Figure 27

1. Hairpin cotter
2. Handle retainer

2. While supporting the handle, remove the hairpin cotters from each side and pivot the handle to the desired operating position (Figure 27).
3. Install the handle retainers and hairpin cotters.

Adjusting the Throttle Control

1. Remove the console cover.
2. Loosen the 2 fasteners securing the throttle control (Figure 28).




Figure 28

1. Fasteners
2. Throttle control

3. Adjust the throttle control to the desired position.
4. Tighten the throttle-control fasteners.
5. Install the previously removed console cover.

Starting the Engine

Note: Ensure that the spark-plug wire is installed on the spark plug.

1. Ensure that the traction and reel-drive levers are in the Disengaged position.

Note: You cannot start the engine if the traction lever is in the engaged position.

2. Move the On/Off switch to the ON position.
3. Move the throttle control to the FAST position.
4. Open the fuel-shutoff valve on the engine.
5. Move the choke lever to the half-open position when starting a cold engine. You may not need the choke when starting a warm engine.
6. Pull the recoil starter handle out until positive engagement results, then pull it vigorously to start the engine. Open the choke as the engine warms up.

Important: Do not pull the recoil rope to its limit or let go of the starter handle when the rope is pulled out because the rope may break or the recoil assembly may be damaged.

Shutting Off the Engine

1. Move the traction and reel drive controls to the DISENGAGED position, the throttle control to SLOW, and the On/Off switch to OFF.
2. Pull the molded spark-plug wire off of the spark plug to prevent the possibility of accidental starting before storing the machine.
3. Close the fuel-shutoff valve before storing or transporting the machine in a vehicle.

Transporting the Machine

Important: Do not run the engine while transporting it in a transport trailer because damage can occur to the machine.

If you are not installing the optional transport wheels, proceed to step 4.

1. Push the kickstand down with foot and pull up on the handle support until the kickstand has rotated forward, over center.
2. Install the transport wheels.
3. To release the kickstand, pull up on the handle and lower the rear of the machine onto the transport wheels.
4. Ensure that the traction and reel drive controls are in the DISENGAGED position and start the engine.
5. Set the throttle control to SLOW, tip the front of the machine up, gradually engage the traction drive, and slowly increase the engine speed.
6. Adjust the throttle to operate the machine at the desired ground speed and transport the machine to the desired destination.

Preparing to Mow

1. Return the traction control lever to the DISENGAGED position, the throttle to the SLOW position, and shut off the engine.
2. Push the kickstand down with your foot and pull up on the handle support until the kickstand has rotated forward, over center.
3. Remove the transport wheels.
4. Carefully lower the machine off the kickstand.

Ensure that the machine is carefully adjusted and is set evenly on both sides of the reel. An improperly adjusted machine is magnified in the appearance of the clipped turf. Remove all foreign objects from the turf prior to mowing. Make sure that everyone, especially children and pets, are clear of the work area.

Mowing Tips

Important: Grass clippings act as a lubricant when mowing. Operating the cutting unit excessively without grass clippings can damage the cutting unit.

- Mow the greens in a straight back-and-forth direction across the green.
- Avoid circular mowing or turning the machine on the greens areas to prevent scuffing.
- Turn the machine off the green by raising the cutting reel (pushing the handle down) and turning on the traction drum.
- Mow at a normal walking pace. Fast speeds saves little time and results in an inferior mowing job.
- To assist in maintaining a straight line across the green and to keep the machine an equal distance from the edge of the previous cut, use the alignment stripes on the basket (Figure 29).




Figure 29

1. Alignment stripes

Operating the Machine in Low Light Conditions

When operating the machine in low light conditions, use the optional LED Light Kit, available from your authorized Toro distributor.

Important: Do not use other light systems with this machine as they will not operate properly with the engine AC output.

Operating the Controls while Mowing

1. Start the engine, set the throttle to a reduced speed, push down on the handle to raise the cutting unit, press the operator-presence control, move the traction lever to the ENGAGED position and transport the machine onto the collar of the green (Figure 30).
2. Move the traction lever to the DISENGAGED position and engage the reel-drive lever (Figure 30).




Figure 30

- | | |
|--|--|
| 1. Traction drive—neutral | 3. Traction drive—engaged (transport) |
| 2. Traction drive neutral and reel drive off | 4. Traction drive and reel drive engaged |

3. Move the traction lever to the ENGAGED position, increase the throttle speed until the machine is traveling at the desired ground speed, drive the machine out onto the green area, lower the front of the machine down, and begin mowing (Figure 30).

Operating the Controls after Mowing

1. Drive off the green, move the reel drive and traction control levers to the DISENGAGED position, and shut off the engine.
2. Empty the grass basket of clippings, install the grass basket on the mower, and transport the machine to storage.

Checking the Operation of the Interlock Switches

Service Interval: Before each use or daily

⚠ CAUTION

If the safety interlock switches are disconnected or damaged, the machine could operate unexpectedly, causing personal injury.

- Do not tamper with the interlock switches.
- Check the operation of the interlock switches daily and replace any damaged switches before operating the machine.

Checking the Operator-Presence Control (OPC) Interlock Switch

1. Push the kickstand down with your foot and pull up on the handle support until the kickstand has rotated forward, over center.
2. Start the engine.
3. With the OPC released, attempt to engage the traction lever ([Figure 31](#)). The traction lever should not engage. If the traction lever engages, the interlock system needs service. Correct the problem before operating; refer to [Servicing the Traction Interlock Switch](#) (page 30).




Figure 31

1. Operator-presence control (OPC)
 2. Traction lever
 3. Brake lever
-
4. With the OPC pressed and the traction lever engaged, release the OPC ([Figure 31](#)). The traction lever should disengage. If the traction lever does not disengage, the interlock system needs service. Correct the problem before operating; refer to [Servicing the Traction Interlock Switch](#) (page 30).
 5. With the OPC pressed and the shift lever moved to the left, engage the traction and reel drive, and release the OPC ([Figure 31](#)). The traction lever should disengage. If the traction lever does not disengage, the interlock system needs service. Correct the problem before operating; refer to [Servicing the Traction Interlock Switch](#) (page 30) or [Adjusting the Reel Control](#) (page 33).
 6. With the OPC pressed and the shift lever moved to the left to engage the traction and reel drive, move the shift lever to the right to disengage the reel drive ([Figure 31](#)). The reel drive should disengage. If the reel drive does not disengage, the interlock system needs service. Correct the problem before operating; refer to [Adjusting the Reel Control](#) (page 33) .
 7. Carefully lower the machine off the kickstand.

Checking the Traction Interlock Switch

1. Push the kickstand down with your foot and pull up on the handle support until the kickstand has rotated forward, over center.
2. With the OPC pressed, the traction lever engaged, and the engine controls in the starting position ([Figure 31](#)). Attempt to start the engine. The engine should not start. If the engine starts,

the interlock switch needs service. Correct the problem before operating. Refer to [Servicing the Traction Interlock Switch \(page 30\)](#).

3. Carefully lower the machine off the kickstand.

Checking the Brake-Interlock Switch

1. Push the kickstand down with your foot and pull up on the handle support until the kickstand has rotated forward, over center.
2. With the traction lever disengaged, the service brake engaged, and the engine controls in the starting position ([Figure 31](#)), attempt to start the engine. The engine should start. If the engine does not start, the interlock switch needs service. Correct the problem before operating the machine; refer to ([page](#)).
3. With the engine running, engage the service brake (not the parking brake), press the OPC, and engage the traction lever ([Figure 31](#)). The engine should labor to overcome the brake but should not shut off. If the engine shuts off immediately, the interlock switch needs service. Correct the problem before operating the machine; refer to ([page](#)).
4. With the engine running, engage the parking-brake latch, press the OPC, and engage the traction lever ([Figure 31](#)). The engine should shut off. If the engine does not shut off, the interlock switch needs service. Correct the problem before operating; refer to ([page](#)).
5. Carefully lower the machine off the kickstand.

Releasing the Transmission

If the machine becomes disabled, you can disengage the drum from the transmission to allow the machine to be maneuvered.

1. On the right rear corner of the machine, locate the traction engage/disengage lever next to the drive housing drum ([Figure 32](#)).




Figure 32

- | | |
|--|---|
| 1. Traction
engage/disengage
lever—engaged | 2. Traction
engage/disengage
lever—disengaged |
|--|---|

2. Rotate the lever rearward to disengage the transmission from the drum.

⚠ CAUTION

Not carefully rotating the lever may cause the spring-loaded lever to strike your hand.

Carefully rotate the lever.

3. Move the machine as needed.

Important: If possible, do not tow the machine. If it is necessary, do not tow greater than 4.8 kph (3 mph); always disengage the transmission from the drum. Failing to do so will likely damage the machine.

4. When finished, rotate the lever forward to engage the transmission to the drum.

Note: The brake is still operational with the transmission disengaged from the drum.

Setting the Machine to Match Turf Conditions

Use the following table to set the machine to match turf conditions.

Bedbars: Standard and Optional (Flex/eFlex 2120 Machines)			
Part Number	Description	Aggressiveness	Comments
106-2468-01	Non-Aggressive	Less	Red, Standard
99-3794-03	Aggressive	More	Black

Bedbars: Standard and Optional (Flex/eFlex 1820 Machines)			
110-2282-01	Non-Aggressive	Less	Red, Standard
110-2281-03	Aggressive	More	Black

Bedknives: Standard and Optional (Flex/eFlex 2120 Machines)			
Part Number	Description	Height-of-cut Range	Comments
115-1880	Microcut-EdgeMax	1.6 to 3.2 mm (0.062 to 0.125 inch)	Standard
93-4262	Microcut	1.6 to 3.2 mm (0.062 to 0.125 inch)	
108-4303	Extended Microcut	1.6 to 3.2 mm (0.062 to 0.125 inch)	Less aggressive
115-1881	Tournament- EdgeMax	3.2 to 6.4 mm (0.125 to 0.25 inch)	
93-4263	Tournament	3.2 to 6.4 mm (0.125 to 0.25 inch)	
108-4302	Extended Tournament	3.2 to 6.4 mm (0.125 to 0.25 inch)	Less aggressive
93-4264	Low Cut	6.4 mm (0.25 inch) and up	

Bedknives: Standard and Optional (Flex/eFlex 1820 Machines)			
117-1530	Microcut-EdgeMax	1.6 to 3.2 mm (0.062 to 0.125 inch)	Standard
98-7261	Microcut	1.6 to 3.2 mm (0.062 to 0.125 inch)	
110-2300	Extended Microcut	1.6 to 3.2 mm (0.062 to 0.125 inch)	Less aggressive
98-7260	Tournament	3.2 to 6.4 mm (0.125 to 0.25 inch)	
117-1532	Tournament- EdgeMax	3.2 to 6.4 mm (0.125 to 0.25 inch)	
110-2301	Low Cut	6.4 mm (0.25 inch) and up	

Rollers (Flex/eFlex 2120 Machines)			
Part Number	Description	Diameter/Material	Comments
04255	Narrow Wiehle	6.4 cm (2.5 inches)/Aluminum	Narrow spaced grooves
04256	Wide Wiehle	6.4 cm (2.5 inches)/Aluminum	More penetration, wide spaced grooves
04257	Full Roller	6.4 cm (2.5 inches)/Steel	Least penetration
04258	Narrow Wiehle—Long	6.4 cm (2.5 inches)/Aluminum	More edge support; 4.3 cm (1.7 inches) longer
04267	Paspalum	6.4 cm (2.5 inches)/Aluminum	Less penetration, softened narrow spaced grooves
115-7356	Rear Roller	5.1 cm (2.0 inches)/Aluminum	Standard rear
120-9595	Rear Roller	5.1 cm (2.0 inches)/Steel	Steel rear

Rollers (Flex/eFlex 1820 Machines)			
120-9607	Narrow Wiehle	6.4 cm (2.5 inches)/Aluminum	Narrow spaced grooves
120-9609	Wide Wiehle	6.4 cm (2.5 inches)/Aluminum	More penetration, wide spaced grooves
120-9611	Full Roller	6.4 cm (2.5 inches)/Steel	Least penetration
121-4681	Narrow Wiehle—Long	6.4 cm (2.5 inches)/Aluminum	More edge support; 4.3 cm (1.7 inches) longer
120-9605	Rear Roller	5.1 cm (2.0 inches)/Aluminum	Standard rear

Maintenance

Note: Determine the left and right sides of the machine from the normal operating position.

Important: When using the machine in conjunction with the Trans Pro 80, always use the stops on the trailer when servicing the machine. Overtipping can result in fuel spills.

The stop on the Rail Ramp Kit requires inserting a broom handle or similar item through the holes behind the wheels.

Recommended Maintenance Schedule(s)

Maintenance Service Interval	Maintenance Procedure
After the first 20 hours	• Change the engine oil. • Clean the fuel-tank screen.
Before each use or daily	• Check the operation of the interlock switches. • Check the engine-oil level.
Every 50 hours	• Change the engine oil. • Clean the air cleaner (more often in dirty or dusty conditions).
Every 100 hours	• Replace the paper air filter element (more often in dirty or dusty conditions). • Check the spark plug. • Clean the fuel-tank screen.
Every 500 hours	• Replace the clutch oil. • Clean the carburetor. • Inspect the intake and exhaust valves. Adjust as necessary.
Every 1,000 hours	• Replace the fuel line. • Inspect the reel-drive belt. • Replace the breather hose. • Inspect the transmission bearings and replace as necessary.
Before storage	• Paint chipped surfaces.

Important: Refer to your engine owner's manual for additional maintenance procedures.

Daily Maintenance Checklist

Important: Duplicate this page for routine use.

Maintenance Check Item	For the week of:						
	Mon.	Tues.	Wed.	Thurs.	Fri.	Sat.	Sun.
Check the safety interlock operation.							
Check the parking brake operation.							
Check that pivot joints operate freely.							
Check the fuel level.							
Check the engine oil level.							
Check the air filter.							
Clean the engine cooling fins.							
Check for unusual engine noises.							
Check for unusual operating noises.							
Check the reel-to-bedknife adjustment.							
Check the height-of-cut adjustment.							
Touch up damaged paint.							

Notation for Areas of Concern		
Inspection performed by:		
Item	Date	Information

Engine Maintenance

Servicing the Engine Oil

Fill the crankcase with approximately 0.6 L (20 fl oz) of the proper viscosity oil before starting. The engine uses any high-quality oil having the American Petroleum Institute (API) service classification SE or higher. Select the proper oil viscosity (weight) based on the ambient temperature. [Figure 33](#) illustrates the temperature/viscosity recommendations.




Figure 33

Note: Using multi-grade oils (5W-20, 10W-30 and 10W-40) will increase oil consumption. Check the oil level more frequently when using them.

Checking the Engine-Oil Level

Service Interval: Before each use or daily

Note: The best time to check the engine oil is when the engine is cool, before it has been started for the day. If it has already been run, allow the oil to drain back down to the sump for at least 10 minutes before checking. If the oil level is at or below the L mark on the dipstick, add oil to bring the oil level to the H mark.

Do not overfill. If the oil level is between the H and L marks, no oil addition is required.

1. Remove the transport wheels (if installed).
2. Position the machine so that the engine is level.




Figure 34

1. Oil-level gauge
 2. Drain plug
-
3. Clean around the oil-level gauge ([Figure 34](#))
 4. Remove the oil-level gauge by rotating it counterclockwise ([Figure 34](#)).
 5. Wipe the oil-level gauge clean and insert it into the filler port. Do not screw the gauge into the port. Then remove it and check the level of the oil. If the level is low, add only enough oil to raise the level until it is between the H and L marks on the gauge ([Figure 35](#)). Check the level of the oil. Do not overfill.




Figure 35

6. Install the oil-level gauge and wipe up any spilled oil.

Changing the Engine Oil

Service Interval: After the first 20 hours

Every 50 hours

1. Start and run the engine for a few minutes to warm the engine oil.
2. At the rear of the machine, place a drain pan under the drain plug ([Figure 34](#)). Loosen the drain plug.

3. Push down on the handle to tip the machine and engine backward, allowing all the oil to run into the drain pan.
4. Install the drain plug and refill the crankcase with the specified oil.
5. Wipe up any spilled oil.
6. Dispose of the used oil properly. Recycle as per local codes.

Servicing the Air Cleaner

Service Interval: Every 50 hours

1. Make sure that the wire is off the spark plug.
2. Remove the wing nut securing the air-cleaner cover to the air cleaner and remove the cover. Clean the cover thoroughly (Figure 36 and Figure 37).




Figure 36

1. Air-cleaner cover




Figure 37

- | | |
|----------------------|---------------------|
| 1. Wing nut | 4. Foam element |
| 2. Air-cleaner cover | 5. Paper element |
| 3. Wing nut | 6. Air-cleaner base |

4. When servicing the foam element, check the condition of the paper element. Replace as required.

Note: Do not use compressed air to clean the paper element.

5. Install the foam element, paper element, and air-cleaner cover.

Important: Do not operate the engine without the air cleaner element because extreme engine wear and damage will result.

3. If the foam element is dirty, remove it from the paper element (Figure 37). Clean it thoroughly.
 - A. Wash the foam element in a solution of liquid soap and warm water. Squeeze it to remove the dirt, but do not twist it because the foam may tear.
 - B. Dry by wrapping in a clean rag. Squeeze the rag and foam element to dry, but do not twist because the foam may tear.
 - C. Saturate the element with clean engine oil. Squeeze the element to remove the excess oil and to distribute the oil thoroughly.

Note: An oil damp element is desirable.

Servicing the Spark Plug

Service Interval: Every 100 hours

Use an NGK BR6HS spark plug or equivalent. The correct air gap is 0.6 to 0.7 mm (0.024 to 0.028 inch).

1. Pull the molded wire off the spark plug (Figure 38).




Figure 38

1. Spark-plug wire

2. Clean around the spark plug and remove the plug from the cylinder head.

Important: Replace a cracked, fouled, or dirty spark plug. Do not sand blast, scrape, or clean the electrodes because engine damage could result from grit entering the cylinder.

3. Set the air gap at 0.6 to 0.7 mm (0.024 to 0.028 inch) as shown in Figure 39. Install the correctly gapped spark plug and tighten it firmly to 23 N·m (17 ft-lb).




Figure 39

1. Center-electrode insulator
2. Side electrode
3. Air gap—0.6 to 0.7 mm (0.024 to 0.028 inch)

Fuel System Maintenance

Cleaning the Fuel-Tank Screen

Service Interval: After the first 20 hours

Every 100 hours/Monthly (whichever comes first)

1. Unscrew and remove the fuel-tank cap from the fuel tank (Figure 40).




Figure 40

1. Fuel-tank cap
2. Fuel-tank screen

2. Remove the fuel-tank screen from inside the fuel tank.
3. Clean the screen in clean fuel and install it in the tank.
4. Install the fuel-tank cap to the fuel tank.

Replacing the Fuel Line

Service Interval: Every 1,000 hours

If fuel leaks from the fuel line, replace the line immediately.

Electrical System Maintenance

Servicing the Traction Interlock Switch

Use the following procedure if the switch needs adjustment or replacement.

1. Make sure that the engine is off.
2. Remove the control panel.
3. Engage the traction lever.




Figure 41

- | | |
|-------------------|---------------------|
| 1. Traction lever | 2. Interlock switch |
|-------------------|---------------------|

4. Loosen the interlock switch mounting fasteners (Figure 41).
5. Place a 1.6 mm (0.062 inch) thick shim between the traction lever and the interlock switch (Figure 41).
6. Tighten the interlock switch mounting fasteners.
7. Engage the traction lever and check the gap. The normal operating range is between 0.76 to 3.05 mm (0.03 to 0.12 inch). With the traction lever engaged, verify that the switch loses continuity. Replace the switch if required.

Servicing the Brake-Interlock Switch

1. Make sure that the engine is off.
2. Remove the control panel.
3. Engage the service-brake lever and engage the parking-brake latch.
4. Loosen the interlock switch mounting fasteners (Figure 42).




Figure 42

- | | |
|------------------------|------------------------|
| 1. Parking-brake latch | 3. Service-brake lever |
| 2. Interlock switch | |

5. Place a 1.6 mm (0.062 inch) thick shim between the parking-brake latch and the interlock switch (Figure 42).
6. Tighten interlock switch mounting fasteners. Check the gap. The latch must not contact the switch.
7. Engage the brake lever and rotate the latch. Verify that the switch loses continuity. Replace the switch if required.

Brake Maintenance

Adjusting the Service/Parking Brake

If the service/parking brake slips when operated, adjust the cable as follows:

1. Move the service/parking brake lever to the OFF position.
2. Remove the control panel.
3. To increase the cable tension, loosen the upper cable jam nut and tighten the lower cable jam nut (Figure 43) until a force of 156 N (35 lb) applied to the brake lever handle is required to release the parking-brake latch. Do not over adjust it or the brake band may drag.




Figure 43

1. Jam nuts
2. Service-brake cable

Belt Maintenance

Inspecting the Reel-Drive Belt

Service Interval: Every 1,000 hours

1. Loosen the flange bolt securing the belt cover and remove the belt cover to expose the belt (Figure 44).




Figure 44

1. Belt cover

2. To adjust the belt tension:
 - A. Loosen the bearing housing mounting nut (Figure 45).




Figure 45

1. Bearing housing mounting nut
2. Reel-drive belt
3. Compression spring

- B. Using a 16 mm (5/8 inch) wrench, rotate the bearing housing to make sure that it operates freely.

- C. Clean any debris from inside the belt compartment and from around the compression spring (Figure 45).
- D. Make sure that the compression spring is applying the proper tension on the belt.
- E. Tighten the bearing housing mounting nut.
- F. Install the belt cover.

Visually Inspecting the Reel Clutch

Remove the rubber plug (Figure 46) from the hole in the front of the transmission to visually inspect the reel clutch when making adjustments.

Important: Replace the plug when finished to prevent water and debris from contaminating the clutch.




Figure 46

- 1. Rubber-hole plug
- 2. Engage/disengage shaft

Engaging/Disengaging the Transmission-Belt Tensioner

The transmission belt is tensioned by a spring loaded idler pulley. If the belt tension has to be engaged/disengaged, use a 3/8 inch wrench to rotate the engage/disengage shaft (Figure 46) to the desired position. Rotating the shaft 1/4 turn clockwise disengages the idler from the belt (Figure 47).

Note: The belt tension must be disengaged prior to removing the transmission cover.




Figure 47

- 1. Engaged
- 2. Disengaged

Controls System Maintenance

Adjusting the Traction Control

Service Interval: Every 500 hours—Replace the clutch oil.

If the traction control does not engage or slips during operation, the traction control may need adjusting.

1. Move the traction control to the ENGAGED position.
2. Measure the distance from the pin on either end of the traction-control spring (Figure 48); if it is not within 7.3 to 7.6 cm (2-7/8 to 3 inches), adjust the clutch according to the steps below.




Figure 48

1. Measure this distance; should be 7.3 to 7.6 cm (2-7/8 to 3 inches)
2. Traction-control spring
3. Clevis pin
4. Turnbuckle
5. Jam nut

- D. Install the turnbuckle to the spring using the clevis pin.
- E. Move the traction control to the ENGAGED position.
- F. Measure the distance from the pin on either end of the traction-control spring (Figure 48); repeat steps A through F until it is within 7.3 to 7.6 cm (2-7/8 to 3 inches).

Adjusting the Reel Control

If the reel control does not properly engage, an adjustment is required.

1. Ensure that the reel control is disengaged.
2. At the transmission bulkhead, adjust the reel-control cable (Figure 49) to attain a spring length of 70.6 to 72.4 mm (2.78 to 2.85 inches).




Figure 49

1. Reel-control cable
 2. Jam nuts
3. At the control handle bulkhead, loosen the reel-control cable until there is slack in the cable (Figure 50).

- A. Disengage the traction-control lever.
- B. Loosen the jam nut on the turnbuckle and remove the clevis pin, disconnecting the spring from the turnbuckle (Figure 48).
- C. Turn the turnbuckle in or out to adjust the length as needed.




Figure 50

- | | |
|---------------------------|-----------------------|
| 1. Jam nuts | 3. Reel-control cable |
| 2. Traction-control cable | |

4. At the control handle bulkhead, tighten the reel-control cable enough to remove the slack from the cable without extending the spring.
5. Check the operation as follows:
 - Verify that the reel clutch teeth disengage when the clutch is released and the reel clutch teeth do not bottom out when engaged.

Note: Remove the rubber plug (Figure 46) from the hole in the front of the transmission to view reel clutch.

 - The reel stopping time must be less than 7 seconds with the reel to bedknife backed off.
 - Refer to the *Service Manual* or contact your authorized Toro distributor for further assistance.

Storage

1. Remove any grass clippings, dirt, and grime from the external parts of the entire machine, especially the engine. Clean the dirt and chaff from the outside of the engine cylinder-head fins and the blower housing.

Important: You can wash the machine with mild detergent and water. Do not pressure wash the machine. Avoid excessive use of water, especially near the shift lever plate, and the engine.

2. For long-term storage (more than 30 days) add stabilizer/conditioner additive to the fuel in the tank.
 - A. Run the engine to distribute conditioned fuel through the fuel system (5 minutes).
 - B. Either shut off the engine, allow it to cool, and drain the fuel tank, or operate the engine until it shuts off.
 - C. Start the engine and run it until it shuts off. Repeat, on CHOKE, until the engine no longer starts.
 - D. Dispose of fuel properly. Recycle as per local codes.

Note: Do not store stabilizer/conditioned fuel over 90 days.
3. Check and tighten all bolts, nuts, and screws. Repair or replace any part that is damaged or defective.
4. Paint all scratched or bare metal surfaces. Paint is available from your Authorized Toro Distributor.
5. Store the machine in a clean, dry garage or storage area. Cover the machine to protect it and keep it clean.

European Privacy Notice

The Information Toro Collects

Toro Warranty Company (Toro) respects your privacy. In order to process your warranty claim and contact you in the event of a product recall, we ask you to share certain personal information with us, either directly or through your local Toro company or dealer.

The Toro warranty system is hosted on servers located within the United States where privacy law may not provide the same protection as applies in your country.

BY SHARING YOUR PERSONAL INFORMATION WITH US, YOU ARE CONSENTING TO THE PROCESSING OF YOUR PERSONAL INFORMATION AS DESCRIBED IN THIS PRIVACY NOTICE.

The Way Toro Uses Information

Toro may use your personal information to process warranty claims, to contact you in the event of a product recall and for any other purpose which we tell you about. Toro may share your information with Toro's affiliates, dealers or other business partners in connection with any of these activities. We will not sell your personal information to any other company. We reserve the right to disclose personal information in order to comply with applicable laws and with requests by the appropriate authorities, to operate our systems properly or for our own protection or that of other users.

Retention of your Personal Information

We will keep your personal information as long as we need it for the purposes for which it was originally collected or for other legitimate purposes (such as regulatory compliance), or as required by applicable law.

Toro's Commitment to Security of Your Personal Information

We take reasonable precautions in order to protect the security of your personal information. We also take steps to maintain the accuracy and current status of personal information.

Access and Correction of your Personal Information

If you would like to review or correct your personal information, please contact us by email at legal@toro.com.

Australian Consumer Law

Australian customers will find details relating to the Australian Consumer Law either inside the box or at your local Toro Dealer.



Toro General Commercial Product Warranty

A Two-Year Limited Warranty

Conditions and Products Covered

The Toro Company and its affiliate, Toro Warranty Company, pursuant to an agreement between them, jointly warrant your Toro Commercial product ("Product") to be free from defects in materials or workmanship for two years or 1500 operational hours*, whichever occurs first. This warranty is applicable to all products with the exception of Aerators (refer to separate warranty statements for these products). Where a warrantable condition exists, we will repair the Product at no cost to you including diagnostics, labor, parts, and transportation. This warranty begins on the date the Product is delivered to the original retail purchaser.

* Product equipped with an hour meter.

Instructions for Obtaining Warranty Service

You are responsible for notifying the Commercial Products Distributor or Authorized Commercial Products Dealer from whom you purchased the Product as soon as you believe a warrantable condition exists. If you need help locating a Commercial Products Distributor or Authorized Dealer, or if you have questions regarding your warranty rights or responsibilities, you may contact us at:

Toro Commercial Products Service Department
Toro Warranty Company
8111 Lyndale Avenue South
Bloomington, MN 55420-1196

952-888-8801 or 800-952-2740
E-mail: commercial.warranty@toro.com

Owner Responsibilities

As the Product owner, you are responsible for required maintenance and adjustments stated in your *Operator's Manual*. Failure to perform required maintenance and adjustments can be grounds for disallowing a warranty claim.

Items and Conditions Not Covered

Not all product failures or malfunctions that occur during the warranty period are defects in materials or workmanship. This warranty does not cover the following:

- Product failures which result from the use of non-Toro replacement parts, or from installation and use of add-on, or modified non-Toro branded accessories and products. A separate warranty may be provided by the manufacturer of these items.
- Product failures which result from failure to perform recommended maintenance and/or adjustments. Failure to properly maintain your Toro product per the Recommended Maintenance listed in the *Operator's Manual* can result in claims for warranty being denied.
- Product failures which result from operating the Product in an abusive, negligent, or reckless manner.
- Parts subject to consumption through use unless found to be defective. Examples of parts which are consumed, or used up, during normal Product operation include, but are not limited to, brake pads and linings, clutch linings, blades, reels, rollers and bearings (sealed or greasable), bed knives, spark plugs, castor wheels and bearings, tires, filters, belts, and certain sprayer components such as diaphragms, nozzles, and check valves, etc.
- Failures caused by outside influence. Conditions considered to be outside influence include, but are not limited to, weather, storage practices, contamination, use of unapproved fuels, coolants, lubricants, additives, fertilizers, water, or chemicals, etc.
- Failure or performance issues due to the use of fuels (e.g. gasoline, diesel, or biodiesel) that do not conform to their respective industry standards.

- Normal noise, vibration, wear and tear, and deterioration.
- Normal "wear and tear" includes, but is not limited to, damage to seats due to wear or abrasion, worn painted surfaces, scratched decals or windows, etc.

Parts

Parts scheduled for replacement as required maintenance are warranted for the period of time up to the scheduled replacement time for that part. Parts replaced under this warranty are covered for the duration of the original product warranty and become the property of Toro. Toro will make the final decision whether to repair any existing part or assembly or replace it. Toro may use remanufactured parts for warranty repairs.

Deep Cycle and Lithium-Ion Battery Warranty:

Deep cycle and Lithium-Ion batteries have a specified total number of kilowatt-hours they can deliver during their lifetime. Operating, recharging, and maintenance techniques can extend or reduce total battery life. As the batteries in this product are consumed, the amount of useful work between charging intervals will slowly decrease until the battery is completely worn out. Replacement of worn out batteries, due to normal consumption, is the responsibility of the product owner. Battery replacement may be required during the normal product warranty period at owner's expense. Note: (Lithium-Ion battery only): A Lithium-Ion battery has a part only prorated warranty beginning year 3 through year 5 based on the time in service and kilowatt hours used. Refer to the *Operator's Manual* for additional information.

Maintenance is at Owner's Expense

Engine tune-up, lubrication, cleaning and polishing, replacement of filters, coolant, and completing recommended maintenance are some of the normal services Toro products require that are at the owner's expense.

General Conditions

Repair by an Authorized Toro Distributor or Dealer is your sole remedy under this warranty.

Neither The Toro Company nor Toro Warranty Company is liable for indirect, incidental or consequential damages in connection with the use of the Toro Products covered by this warranty, including any cost or expense of providing substitute equipment or service during reasonable periods of malfunction or non-use pending completion of repairs under this warranty. Except for the Emissions warranty referenced below, if applicable, there is no other express warranty. All implied warranties of merchantability and fitness for use are limited to the duration of this express warranty.

Some states do not allow exclusions of incidental or consequential damages, or limitations on how long an implied warranty lasts, so the above exclusions and limitations may not apply to you. This warranty gives you specific legal rights, and you may also have other rights which vary from state to state.

Note regarding engine warranty:

The Emissions Control System on your Product may be covered by a separate warranty meeting requirements established by the U.S. Environmental Protection Agency (EPA) and/or the California Air Resources Board (CARB). The hour limitations set forth above do not apply to the Emissions Control System Warranty. Refer to the Engine Emission Control Warranty Statement supplied with your product or contained in the engine manufacturer's documentation for details.

Countries Other than the United States or Canada

Customers who have purchased Toro products exported from the United States or Canada should contact their Toro Distributor (Dealer) to obtain guarantee policies for your country, province, or state. If for any reason you are dissatisfied with your Distributor's service or have difficulty obtaining guarantee information, contact the Toro importer.