

LAWN-BOY®

21" SILVER SERIES WALK-BEHIND MOWER

MODEL NO.10201-5900001 & UP

MODEL NO.10301-5900001 & UP

PARTS CATALOG

PRODUCT CHANGES

In an effort to make improvements available to LAWN-BOY owners as quickly as possible, minor changes are incorporated into LAWN-BOY products from time to time that do not become immediately shown in the Parts Catalog. If such a change has been made in your unit, which is not reflected in your Parts Catalog, see your LAWN-BOY Distributor or his Authorized LAWN-BOY Service Dealer for information and part numbers.

IDENTIFICATION AND ORDERING

MODEL AND SERIAL NUMBERS

The Product has two identification numbers; a model number and a serial number. The two numbers are stamped on a plate mounted on the deck. In any correspondence concerning the Product, supply model and serial numbers to assure that correct information and replacement parts are obtained.

To order replacement parts from an Authorized Service Dealer, supply the following information:

1. Model and serial number.
2. Part number, description, and the quantity of part(s) desired.


NOTE: Do not order by reference number if a parts catalog is being used; use the PART NUMBER.

TABLE OF CONTENTS

Description	Page	Description	Page
2 Cycle Engine, Fuel Tank And Blade Assembly	1	Handle Assembly	6
Deck And Wheel Assembly (Model No. 10201) ...	2	Engine Assembly	7-10
Deck And Wheel Assembly (Model No. 10301) ...	3	Recoil Starter Assembly	11
Rear Axle Assembly (Model No. 10301)	4	Carburetor Assembly	12
Gear Case Assembly (Model No. 10301)	5	Lawn-Boy Part Number Index	13-14

Accessories

Description	Model / Parts No.	Description	Model / Parts No.
Rear Bagging Kit	89800	Leaf Bag	89804
Side Bagging Kit	89814	Leaf Bag Kit w/Chute	89811
Leaf Shredder Kit	89860	Mow & Feed Fertilizer Spreader	52070




C-2126

2 CYCLE ENGINE, FUEL TANK & BLADE ASSEMBLY

Ref. No.	Part No.	Description	No. Used
1		Engine Ass'y - 2 Cycle	1
2	93-3175	Baffle	1
3	92-8615	Applique	1
4	93-1230	Cover	1
5	93-4302	Screw	3
6	92-1701	Stop - Rope	1
7	93-3660	Cap Assembly - Fuel (Includes Ref. #2, 4, 8, & 12)	1
8	609150	Baffle - Foam	1
9	92-6380	Shroud & Tank Ass'y	1
10	92-9569	Decal - Shroud (Model No. 10201 Only)	1
*	92-9570	Decal - Shroud, (Model No. 10301 Only)	1

Ref. No.	Part No.	Description	No. Used
11	612782	Hose - Gas	1
12	613311	Gasket	1
13	92-1624	Screw - Engine Mount	3
14	603164	Nut - Blade	1
15	92-1630	Fan - Mulching	1
16	612543	Blade - 21"	1
17	613227	Screw - Set, Pulley	1
18	92-6542	Pulley - Engine	1
19	677525	Plate & Collar Ass'y	1
20	44-2750	Body - Primer	1
21	44-3174	Hose - Primer	1
22	66-7460	Bulb - Primer	1

*Not Illustrated




C-1288A

DECK & WHEEL ASSEMBLY (Model No. 10201 Only)

Ref. No.	Part No.	Description	No. Used
1	92-8630	Cover Plate, Mulch	1
*	607560	Cover Plate	1
2	604604	Grommet - Plastic	2
3	614677	Screw - Thread Forming	2
4	92-1097	Decal - Danger (English)	1
*	92-5428	Decal - Danger (French/English)	1
5	614682	Knob	1
6	39-5770	Decal - Danger (English)	1
*	92-5429	Decal - Danger (French/English)	1
7	92-7742	Handle Bracket Ass'y - RH	1
8	16-4359	Housing & Baffle Ass'y (Incl. ref. #2- 6, 9, 11 & 29)	1
10	92-7743	Handle Bracket Ass'y - LH	1
11	92-2915	Decal - H. O. C. L.H.	2
*	92-2914	Decal - H. O. C. R.H.	2
12	3296-29	Nut	4

Ref. No.	Part No.	Description	No. Used
13	93-7250	Decal - Warning	1
*	93-7253	Decal - Warning (French)	1
14	92-1005	Spring Arm Assembly	2
15	614672	Bolt - Shoulder	4
16	684777	Wheel Ass'y - 8"	2
17	614650	Bolt - Wheel	2
18	322-3	Screw - Hex Head	4
19	92-8647	Shield - Trailing	1
20	3296-39	Nut	2
21	92-1008	Knob - H. O. C. Lever	4
22	614687	Spring Arm Assembly, Front	2
23	92-1099	Bolt - Wheel	2
24	684776	Wheel Ass'y - 6"	2
25	40-1940	Washer - Wheel Bolt	4
26	614637	Bracket - H. O. C.	4
27	92-4890	Washer	4
28	92-4881	Plate - H. O. C. Front	2
29	613765	Nut - Cage	1
30	92-7731	Plate - Baffle	2

*Not Illustrated




C-1289A

DECK & WHEEL ASSEMBLY (Model No. 10301 Only)

Ref. No.	Part No.	Description	No. Used	Ref. No.	Part No.	Description	No. Used
1	92-8630	Cover Plate, Mulch	1	15	605120	Grommet - Shroud Mtg.	1
*	607560	Cover Plate	1	16	92-7735	Gear Case Ass'y	1
2	92-1097	Decal - Danger (English)	1	17	92-7724	Handle Bracket Ass'y - LH	1
*	92-5428	Decal - Danger (French/English)	1	20	322-3	Screw - Hex. Hd.	6
3	604604	Grommet - Plastic	2	21	92-8647	Shield - Trailing	1
4	92-2915	Decal - H. O. C. LH	2	22	3296-29	Nut	6
*	92-2914	Decal - H. O. C. RH	2	23	92-1008	Knob - H. O. C.	4
5	39-5770	Decal - Danger (English)	1	24	614687	Arm - Spring	2
*	92-5429	Decal - Danger (French/English)	1	25	614672	Bolt - Shoulder	2
6	614677	Screw - Thread Forming	2	26	684776	Wheel Assembly - 6"	2
7	614682	Knob	1	27	92-1099	Bolt - Wheel	2
8	92-7723	Handle Bracket Ass'y - RH	1	28	40-1940	Washer	2
9	614671	Cover - Drive	1	29	614637	Bracket - H. O. C.	2
10	92-9665	Screw	1	30	92-4890	Washer	2
11	49-2040	Screw - Thread Forming	2	31	92-4881	Plate H. O. C.	2
12	92-7728	Guide - Transmission	1	32	613765	Nut - Cage	1
13	93-7250	Decal - Warning	1	33	16-4369	Housing & Baffle Ass'y (Incl. Ref. # 2-6, 13 & 32)	1
*	93-7253	Decal - Warning (French)	1	34	92-7731	Plate - Baffle	2

*Not Illustrated




C-1291

REAR AXLE ASSEMBLY (Model No. 10301 Only)

Ref. No.	Part No.	Description	No. Used
2	614447	Spacer - Axle Shaft	2
3	92-1004	Spring Arm Ass'y	2
4	70-9760	Bushing	2
5	92-7746	Pivot Arm Ass'y - Rear	2
6		Fitting - Grease (Ref.)	2
7	47-2900	Bushing	2
8	65-4730	Washer - Thrust Pivot Arm	2
9	65-4740	Washer - Thrust, Keyed	4
10	65-2720	Ring - Klip	4
11	65-4710	Ring - Friction	2
12	65-4760	Washer - Clutch, Plastic	2
13	66-6050	Key - Rocking LH	1
*	66-6040	Key - Rocking, RH	1

Ref. No.	Part No.	Description	No. Used
14	65-4750	Gear - Pinion	2
15	65-4720	Spring - Compression	2
16	614427	Cover Wheel	2
17	92-1057	Bolt - Wheel	2
18	92-1042	Wheel Ass'y - 8"	2
19	614426	Washer - Stepped	2
21	610358	Nut	2
22	32144-85	Screw	2
23	92-1043	"V" Belt	1
24	92-1008	Knob	2

*Not Illustrated




C-1292

GEAR CASE ASSEMBLY (Model No. 10301 Only)

Ref. No.	Part No.	Description	No. Used
1	32144-4	Screw - Taptite	4
2	614668	Cover - Gear Case	1
3	55-3760	Pinion - 15 Tooth	1
4	614696	Shaft - Intermediate	1
5	36-4791	Washer	2
6	60-8750	Bushing	2
7	614666	Shaft - Output	1
8	3285-19	Pin - Groove	2
9	60-8850	Bushing - Output	2


Ref. No.	Part No.	Description	No. Used
10	92-7727	Gearcase	1
11	62-6660	Spacer	1
12	614669	Pulley - Half	2
13	3256-24	Washer	1
14	3296-5	Nut	1
15	38-7820	Bearing - Ball	1
16	60-8890	Gear - Bevel Pinion	1
17	36-4780	Washer - Thrust	2
18	614596	Gear 34 Tooth	1



HANDLE ASSEMBLY

Ref. No.	Part No.	Description	No. Used
1	92-7737	Handle - Upper	1
2	92-7720	Guide - Rope	1
3	612825	Handle - Starter	1
4	612824	Clip - Rope Insert	1
5	92-5412	Stop - Pivot	2
6	92-1002	Bail - Brake	1
7	92-1001	Bail - Control (Model No. 10301 Only)	1
8	92-7726	Cable - Traction	1
9	614697	Screw - Handle	2
10	614243	Knob - Handle	2
11	614643	Handle - Lower	1
12	614693	Anchor - Cable (Lower) (Model No. 10301 Only)	1
13	614249	Tie Strap	A/R


Ref. No.	Part No.	Description	No. Used
14	92-7729	Anchor - Cable (Upper) (Model No. 10301 Only)	1
15	321-48	Screw (Model No. 10201 Only)	1
	321-49	Screw (Model No. 10301 Only)	1
16	3296-73	Nut	1
17	92-7738	Cable - Brake	1
18	92-7734	Cable - Throttle	1
19	321-50	Screw	1
20	92-8632	Washer (Model No. 10201 Only)	1
21	93-3653	Guard - Handle (Qt'y 2 Model No. 10201 Only)	1



C-2128A

ENGINE ASSEMBLY

Ref. No.	Part No.	Description	No. Used	Ref. No.	Part No.	Description	No. Used
1	614699	Screw	3	6	607199	Key	1
2	130743	Nut	1	7	614702	Screw	4
3	614640	Hub - Starter	1	8	93-4304	Shroud Assembly	1
4	684743	Flywheel	1	9	316959	Washer - Lock	1
5	93-1216	Base - Shroud	1				




C-2129A

ENGINE ASSEMBLY (Continued)

Ref. No.	Part No.	Description	No. Used
2	609482	Screw	2
3	610383	Retainer – Filter	1
4	93-1231	Cover – Air Cleaner	1
5	609493	Element – Filter Air	1
6	611545	Plug	2

Ref. No.	Part No.	Description	No. Used
7	44-3174	Hose – Primer	1
8	92-9695	Carburetor Assembly (Incl. Ref. #9)	1
9	92-4948	Gasket – Carburetor	2
10	93-1221	Shield – Carburetor	1




C-1296

ENGINE ASSEMBLY (Continued)

Ref. No.	Part No.	Description	No. Used
1	92-9693	Short Block (Incl. Ref. #2, Ref. #9 pg. 8)	1
2	93-1233	Gasket - Exhaust	1
3	92-1152	CD Ignition	1
*	681678	Cover & Terminal	1
4	614009	Plug - Spark	1
5	684049	CD Ignition (Incl. Ref. #3)	1
6	613208	Screw - Hex. Washer Hd.	2
7	66-5370	Spring - Compression	1
8	66-5380	Brake Plate Assembly	1
9	92-9698	Screw - Shoulder	1
10	614702	Screw	1

Ref. No.	Part No.	Description	No. Used
11	3290-459	Rivet - Plastic	2
12	92-2925	Strap - Insulation	1
13	60-9010	Strap - Ground	1
14	92-1156	Wire - Brake Switch Lead	1
15	53-4690	Stop - Ground Strap	1
16	12-5450	Screw - Thread Forming	1
17	14-6009	Mounting Plate	1
18	614654	Plate - Muffler	1
19	607601	Screw	4
20	614681	Baffle	1
21	609471	Screw	3
22	614674	Cover - Muffler	1

*Not Illustrated




C-1295

ENGINE ASSEMBLY (Continued)

Ref. No.	Part No.	Description	No. Used
1	681737	Set - Ring	1
3	92-4923	Piston & Ring Set	1
*	92-4925	Piston & Connecting Rod (Incl. Ref. #1-8, 12, & 13)	1
4	606608	Pin - Wrist	1
5	303712	Ring - Retaining	2
6	92-4921	Connecting Rod Assembly (Incl. Ref. #6-8, 12, & 13)	1
7	92-4927	Bearing	1
8	677982	Liner - Split (Set of 2)	1
9	92-6375	Crankshaft	1
10	681830	Bearing - Upper Main	1
11	611396	Seal - Oil	2
12	683911	Bearing - Needle	1

Ref. No.	Part No.	Description	No. Used
13	611393	Screw - Hex. Hd.	2
14	614636	Screw - Torx. Washer Hd.	4
15	93-4311	Cylinder & Crankcase Cover (Incl. Ref. #14, 16-18, 20, 21, & Sealer)	1
16	602588	Reed - Carburetor	1
17	602587	Reed - Backup Plate	1
18	612872	Screw	2
19	681831	Bearing - Needle	1
20	609629	Dowel	1
21	609123	Plug - Core	4
*	684725	Cylinder & Crankcase Ass'y	1
*	610372	Sealer	1

*Not Illustrated




C-1309

RECOIL STARTER ASSEMBLY

Ref. No.	Part No.	Description	No. Used
1	93-4304	Housing Assembly	1
2	92-4928	Rope - Starter	1
3	92-4929	Pulley Assembly	1
4	92-4930	Spring - Dog	2
5	92-4931	Dog	2

Ref. No.	Part No.	Description	No. Used
6	92-9692	Retainer	1
7	92-4933	Screw	1
8	92-4934	Spring	1
9	92-4935	Spring Keeper Assembly	1



C-2130A

CARBURETOR ASSEMBLY

Ref. No.	Part No.	Description	No. Used	Ref. No.	Part No.	Description	No. Used
1	92-6376	Air Vane & Shaft	1	12	603145	Spring	1
2	610165	Retainer - Speed Control	1	13	602850	Gasket	1
3	93-1225	Lever - Speed Adjust	1	14	92-6371	Nozzle	1
4	610834	Collar - Air Vane	1	15	611071	Filter - Fuel	1
5	92-4944	Spring - Governor	1	16	678113	Float & Arm Assembly	1
6	92-6373	Disc - Throttle	1	17	92-6389	Pin	1
7	92-4949	Bracket - Throttle Control	1	18	92-9691	Float Chamber	1
8	613269	Screw	2	19	608850	Screw	4
9	92-6377	Carburetor Body	1	20	612383	Washer	1
10	92-9697	Kit - Float Valve, Body & Seat (Incl. Ref. #12)	1	21	92-6370	Main Jet	1
				*	92-6385	Jet - High Altitude	1
				*	92-9695	Carburetor Assembly	1

*Not Illustrated

LAWN-BOY PART NUMBER INDEX

Part No.	Description	Pg. No.	Ref. No.	Qty.	Part No.	Description	Pg. No.	Ref. No.	Qty.
130743	Nut	7	2	1	614674	Cover - Muffler	9	22	1
303712	Ring - Retaining	10	5	2	614677	Screw - Thread Forming	2	3	2
316959	Washer - Lock	7	9	1	614677	Screw - Thread Forming	3	6	2
602587	Reed - Backup Plate	10	17	1	614681	Baffle	9	20	1
602588	Reed - Carburetor	10	16	1	614682	Knob	2	5	1
602850	Gasket	12	13	1	614682	Knob	3	7	1
603145	Spring	12	12	1	614687	Arm - Spring	3	24	2
603164	Nut - Blade	1	14	1	614687	Spring Arm Assembly, Front	2	22	2
604604	Grommet - Plastic	2	2	2	614693	Anchor - Cable (Lower)	6	12	1
604604	Grommet - Plastic	3	3	2	614696	Shaft - Intermediate	5	4	1
605120	Grommet - Shroud Mtg.	3	15	1	614697	Screw - Handle	6	9	2
606608	Pin - Wrist	10	4	1	614702	Screw	7	7	4
607199	Key	7	6	1	614702	Screw	9	10	1
607560	Cover Plate	2	*	1	677525	Plate & Collar Ass'y	1	19	1
607560	Cover Plate	3	*	1	677982	Liner - Split (Set of 2)	10	8	1
607601	Screw	9	19	4	678113	Float & Arm Assembly	12	16	1
608850	Screw	12	19	4	681737	Set - Ring	10	1	1
609123	Plug - Core	10	21	4	681830	Bearing - Upper Main	10	10	1
609150	Baffle - Foam	1	8	1	681831	Bearing - Needle	10	19	1
609471	Screw	9	21	3	683911	Bearing - Needle	10	12	1
609482	Screw	8	2	2	684049	CD Ignition	9	5	1
609493	Element - Filter Air	8	5	1	684725	Cylinder & Crankcase Ass'y	10	*	1
609629	Dowel	10	20	1	684743	Flywheel	7	4	1
610165	Retainer - Speed Control	12	2	1	684776	Wheel Ass'y - 6	2	24	2
610358	Nut	4	21	2	684776	Wheel Assembly - 6	3	26	2
610372	Sealer	10	*	1	684777	Wheel Ass'y - 8	2	16	2
610383	Retainer - Filter	8	3	1	12-5450	Screw - Thread Forming	9	16	1
610834	Collar - Air Vane	12	4	1	14-6009	Mounting Plate	9	17	1
611071	Filter - Fuel	12	15	1	16-4359	Housing & Baffle Ass'y	2	8	1
611393	Screw - Hex. Hd.	10	13	2	16-4369	Housing & Baffle Ass'y	3	33	1
611396	Seal - Oil	10	11	2	36-4780	Washer - Thrust	5	17	2
611545	Plug	8	6	2	36-4791	Washer	5	5	2
612383	Washer	12	20	1	38-7820	Bearing - Ball	5	15	1
612543	Blade - 21	1	16		39-5770	Decal - Danger (English)	3	5	1
612782	Hose - Gas	1	11	1	39-5770	Decal - Danger (English)	2	6	1
612824	Clip - Rope Insert	6	4	1	40-1940	Washer	3	28	2
612825	Handle - Starter	6	3	1	40-1940	Washer - Wheel Bolt	2	25	4
612872	Screw	10	18	2	44-2750	Body - Primer	1	20	1
613208	Screw - Hex. Washer Hd.	9	6	2	44-3174	Hose - Primer	8	7	1
613227	Screw - Set, Pulley	1	17	1	44-3174	Hose - Primer	1	21	1
613269	Screw	12	8	2	47-2900	Bushing	4	7	2
613311	Gasket	1	12	1	49-2040	Screw - Thread Forming	3	11	2
613765	Nut - Cage	2	29	1	53-4690	Stop - Ground Strap	9	15	1
613765	Nut - Cage	3	32	1	55-3760	Pinion - 15 Tooth	5	3	1
614009	Plug - Spark	9	4	1	60-8750	Bushing	5	6	2
614243	Knob - Handle	6	10	2	60-8850	Bushing - Output	5	9	2
614249	Tie Strap	6	13	A/R	60-8890	Gear - Bevel Pinion	5	16	1
614426	Washer - Stepped	4	19	2	60-9010	Strap - Ground	9	13	1
614427	Cover Wheel	4	16	2	62-6660	Spacer	5	11	1
614447	Spacer - Axle Shaft	4	2	2	65-2720	Ring - Klip	4	10	4
614596	Gear 34 Tooth	5	18	1	65-4710	Ring - Friction	4	11	2
614636	Screw - Torx. Washer Hd.	10	14	4	65-4720	Spring - Compression	4	15	2
614637	Bracket - H. O. C.	2	26	4	65-4730	Washer - Thrust Pivot Arm	4	8	2
614637	Bracket - H. O. C.	3	29	2	65-4740	Washer - Thrust, Keyed	4	9	4
614640	Hub - Starter	7	3	1	65-4750	Gear - Pinion	4	14	2
614643	Handle - Lower	6	11	1	65-4760	Washer - Clutch, Plastic	4	12	2
614650	Bolt - Wheel	2	17	2	66-5370	Spring - Compression	9	7	1
614654	Plate - Muffler	9	18	1	66-5380	Brake Plate Assembly	9	8	1
614666	Shaft - Output	5	7	1	66-6040	Key - Rocking, RH	4	*	1
614668	Cover - Gear Case	5	2	1	66-6050	Key - Rocking LH	4	13	1
614669	Pulley - Half	5	12	2	66-7460	Bulb - Primer	1	22	1
614671	Cover - Drive	3	9	1	70-9760	Bushing	4	4	2
614672	Bolt - Shoulder	2	15	4	92-1001	Bail - Control	6	7	1
614672	Bolt - Shoulder	3	25	2	92-1002	Bail - Brake	6	6	1

*Not Illustrated

LAWN-BOY PART NUMBER INDEX (Cont.)

Part No.	Description	Pg. No.	Ref. No.	Qty.	Part No.	Description	Pg. No.	Ref. No.	Qty.
92-1004	Spring Arm Ass'y	4	3	2	92-7726	Cable - Traction	6	8	1
92-1005	Spring Arm Assembly	2	14	2	92-7727	Gearcase	5	10	1
92-1008	Knob	4	24	2	92-7728	Guide - Transmission	3	12	1
92-1008	Knob - H. O. C. Lever	2	21	4	92-7729	Anchor - Cable (Upper)	6	14	1
92-1008	Knob - H. O. C.	3	23	4	92-7731	Plate - Baffle	2	30	2
92-1038	Cable - Brake	6	17	1	92-7731	Plate - Baffle	3	34	2
92-1042	Wheel Ass'y - 8	4	18	2	92-7734	Cable - Throttle	6	18	1
92-1043	VBelt	4	23	1	92-7735	Gear Case Ass'y	3	16	1
92-1057	Bolt - Wheel	4	17	2	92-7737	Handle - Upper	6	1	1
92-1097	Decal - Danger (English)	3	2	1	92-7742	Handle Bracket Ass'y - RH	2	7	1
92-1097	Decal - Danger (English)	2	4	1	92-7743	Handle Bracket Ass'y - LH	2	10	1
92-1099	Bolt - Wheel	2	23	2	92-7746	Pivot Arm Ass'y - Rear	4	5	2
92-1099	Bolt - Wheel	3	27	2	92-8615	Applique	1	3	1
92-1152	CD Ignition	9	3	1	92-8630	Cover Plate, Mulch	2	1	1
92-1156	Wire - Brake Switch Lead	9	14	1	92-8630	Cover Plate, Mulch	3	1	1
92-1624	Screw - Engine Mount	1	13	3	92-8632	Washer	6	20	1
92-1630	Fan - Mulching	1	15	1	92-8647	Shield - Trailing	2	19	1
92-1701	Stop - Rope	1	6	1	92-8647	Shield - Trailing	3	21	1
92-2914	Decal - H. O. C. R.H.	2	*	2	92-9569	Decal - Shroud	1	10	1
92-2914	Decal - H. O. C. RH	3	*	2	92-9570	Decal - Shroud,	1	*	1
92-2915	Decal - H. O. C. L.H.	2	11	2	92-9665	Screw	3	10	1
92-2915	Decal - H. O. C. LH	3	4	2	92-9691	Float Chamber	12	18	1
92-2925	Strap - Insulation	9	12	1	92-9692	Retainer	11	6	1
92-4881	Plate - H. O. C. Front	2	28	2	92-9693	Short Block	9	1	1
92-4881	Plate H. O. C.	3	31	2	92-9695	Carburetor Assembly	12	*	1
92-4890	Washer	2	27	4	92-9695	Carburetor Assembly	8	8	1
92-4890	Washer	3	30	2	92-9697	Kit - Float Valve, Body	12	10	1
92-4921	Connecting Rod Assembly	10	6	1	92-9698	Screw - Shoulder	9	9	1
92-4923	Piston & Ring Set	10	3	1	93-1216	Base - Shroud	7	5	1
92-4925	Piston & Connecting Rod	10	*	1	93-1221	Shield - Carburetor	8	10	1
92-4927	Bearing	10	7	1	93-1225	Lever - Speed Adjust	12	3	1
92-4928	Rope - Starter	11	2	1	93-1230	Cover	1	4	1
92-4929	Pulley Assembly	11	3	1	93-1231	Cover - Air Cleaner	8	4	1
92-4930	Spring - Dog	11	4	2	93-3175	Baffle	1	2	1
92-4931	Dog	11	5	2	93-3653	Guard - Handle	6	21	1
92-4933	Screw	11	7	1	93-3660	Cap Assembly - Fuel	1	7	1
92-4934	Spring	11	8	1	93-4302	Screw	1	5	3
92-4935	Spring Keeper Assembly	11	9	1	93-4304	Housing Assembly	11	1	1
92-4944	Spring - Governor	12	5	1	93-4304	Shroud Assembly	7	8	1
92-4948	Gasket - Carburetor	8	9	2	93-4311	Cylinder & Crankcase Cover	10	15	1
92-4949	Bracket - Throttle Control	12	7	1	93-7250	Decal - Warning	2	13	1
92-5412	Stop - Pivot	6	5	2	93-7250	Decal - Warning	3	13	1
92-5428	Decal - Danger	2	*	1	93-7253	Decal - Warning (French)	2	*	1
92-5428	Decal - Danger	3	*	1	93-7253	Decal - Warning (French)	3*		1
92-5429	Decal - Danger	2	*	1	321-48	Screw	6	15	1
92-5429	Decal - Danger	3	*	1	321-49	Screw	6		1
92-6370	Main Jet	12	21	1	321-50	Screw	6	19	1
92-6371	Nozzle	12	14	1	322-3	Screw - Hex Head	2	18	4
92-6373	Disc - Throttle	12	6	1	322-3	Screw - Hex. Hd.	3	20	6
92-6375	Crankshaft	10	9	1	3256-24	Washer	5	13	1
92-6376	Air Vane & Shaft	12	1	1	3285-19	Pin - Groove	5	8	2
92-6377	Carburetor Body	12	9	1	3290-459	Rivet - Plastic	9	11	2
92-6380	Shroud & Tank Ass'y	1	9	1	3296-5	Nut	5	14	1
92-6385	Jet - High Altitude	12	*	1	3296-29	Nut	2	12	4
92-6389	Pin	12	17	1	3296-29	Nut	3	22	6
92-6542	Pulley - Engine	1	18	1	3296-39	Nut	2	20	2
92-7720	Guide - Rope	6	2	1	3296-73	Nut	6	16	1
92-7723	Handle Bracket Ass'y - RH	3	8	1	32144-4	Screw - Taptite	5	1	4
92-7724	Handle Bracket Ass'y - LH	3	17	1	32144-85	Screw	4	22	2

*Not Illustrated