

LAWN-BOY®

Silver Series® Lawnmower

Model No. 10356 - 240000001 and up.

Parts Catalog

Ordering Replacement Parts

To order replacement parts, please supply the part number, the quantity, and the description of each part desired.

Understanding Reference Numbers

Each Identified part in an illustration has a reference number. The reference number for a part also appears in the parts list, along with other information about the part.

This catalog uses two special reference number formats, one to indicate parts in a service assembly and another to indicate the quantity of a given part in an illustration.

Service Assembly Reference Numbers

Parts in service assemblies have reference numbers in the form a:b. The a represents the reference number of the entire service assembly and the b represents a sequential number unique to each part within the service assembly.

For example, a wheel assembly might be identified by reference number 6, the tire by 6:1, the valve by 6:2, and the wheel by 6:3. When you order the assembly identified by reference number 6, you receive all parts identified by reference numbers 6:1, 6:2, and 6:3. However, you may also order any part individually. Reference numbers of this type appear in illustrations and in part lists.

Reference Numbers Indicating Quantity

In an illustration, if a reference number indicates more than one part, the reference number has the form nX y. The n represents the quantity of the part, the X is the multiplication symbol, and the y represents the reference number.

For example, in an illustration, the reference number 2X 37 means that two of the parts identified by reference number 37 are indicated.

Part Description Abbreviations

Part descriptions in this catalog may include the following abbreviations.


AR.	as required	HYD.	hydraulic
ASM.	assembly	INC.	incorporated
CARR.	carriage	LH.	left hand
DEG.	degrees	NI.	nylon insert
FH.	flat head	PPH.	phillips pan head
GA.	gauge	PTH.	phillips truss head
HF.	hex flange	PTO.	power take off
HH.	hex head	RH.	right hand
HHF.	hex head flange	SFH.	slotted fillister head
HHFTF.	hex head flange thread forming	SHH.	slotted hex head
HJ.	hex jam	SHWH.	slotted hex washer head
HLH.	hex lag head	SPH.	slotted pan head
HOC.	height-of-cut	SQH.	square head
HS.	hex	SRH.	slotted round head
HSBH.	hex socket button head	STD.	standard
HSFH.	hex socket flat head	TAP.	self tapping
HS.	hex socket head	TTH.	torx truss head
HWH.	hex washer head	WH.	wing head
HWHTF.	hex washer head thread forming		

Footnotes

- ❶ Not illustrated
- ❷ Not serviced separately
- ❸ Included in Repair Kit No. 632809
- ❹ Obtain parts from your local Tecumseh dealer
- ❺ Included in Repair Kit No. 37613

Contents


Description	Page	Description	Page
Housing Assembly 3	Carburetor Assembly No. 640303 Tecumseh Model No. LV195EA-362005B 12
Gear Case Assembly No. 104-7671 4	Recoil Starter Assembly No. 590739 Tecumseh Model No. LV195EA-362005B 13
Gear Case and Wheel Assembly 5	Recoil Starter Assembly No. 590702 (Optional) Tecumseh Model No. LV195EA-362005B 14
Engine and Blade Assembly 6		
Handle Assembly 7		
Engine Assembly No. 1 Tecumseh Model No. LV195EA-362005B 8		
Engine Assembly No. 2 Tecumseh Model No. LV195EA-362005B 10		



Housing Assembly


Ref	Part No.	Qty.	Description
1	40-1940	2	Washer
2	95-7403-03	2	Bracket-Height Adjustment, Wheel
3	92-7731	2	Plate-Baffle
4	92-4890	2	Washer-Wheel
5	92-4881-03	2	Plate-Height, Adjustment
10	98-4477	1	Deck ASM
10:3	43-8480	1	Decal-Danger
10:4	613765	1	Nut-Cage
10:6	99-6018	1	Decal-Warning
10:7	92-2914	1	Decal-Hoc, LH
10:8	92-2915	1	Decal-Hoc, RH
10:9	93-7250	1	Decal-Warning
10:10	94-1610	2	Nut-Clip
14	614677	2	Screw-Sems
17	92-8630	1	Plate-Mulch
18	98-8332	1	Knob
19	105-8602	1	RH Bracket ASM
21	95-7068	1	Cover-Drive
22	92-9665	1	Screw
23	65-5221	2	Screw-HWHTF
24	92-7728-03	1	Guide-Transmission
25	605120	1	Nut-Clip
26	104-7671	1	Gear Case ASM
27	105-8604	1	LH Bracket ASM

Ref	Part No.	Qty.	Description
28	322-3	6	Screw-HH
29	92-8647	1	Shield-Trailing
30	3296-29	6	Nut-Lock, NI
32	92-1008	2	Knob-Lever, Height Adjustment
33	614687	2	Arm-Front Spring
34	614672	2	Bolt-Shoulder
35	92-1099	2	Bolt-Shoulder
36	684776	2	Wheel And Tire ASM
99	95-7052	1	Plate-Opening, Chute



Gear Case Assembly No. 104-7671


Ref	Part No.	Qty.	Description
1	104-7619	1	Case-Gear
2	614668-03	1	Cover-Case, Gear
3	32144-4	4	Screw-HWH
4	32151-68	1	Ring-Retaining
5	3256-24	1	Washer-Flat
6	3285-19	2	Pin-Groove
7	3296-5	1	Nut-Lock, NI
8	36-4780	2	Washer
9	36-4791	2	Washer-Thrust
10	60-8750	2	Bushing
11	60-8850	2	Bushing
12	614696	1	Shaft-Intermediate
13	614669	2	Half-Pulley
14	100-1048	1	Bearing-Ball
15	62-6660	1	Spacer
16	104-7668	1	Gear-15t Spur, 37t Bevel
17	104-7667	1	Gear-Pinion, Bevel
18	614596	1	Gear
19	104-7670	1	Shaft-Output



Gear Case and Wheel Assembly


Ref	Part No.	Qty.	Description
1	92-1057	2	Bolt-Shoulder
2	92-1042	2	Wheel And Tire ASM
2:3		1	Wheel ASM
2:3:1	27-6250	2	Bushing
3	65-2720	4	Klipring-Locking
4	65-4740	4	Washer-Thrust, Keyed
5	66-6050	1	Key-Rocking, LH
6	66-6040	1	Key-Rocking, RH
7	65-4710	2	Ring-Friction
8	92-7746	2	Rear Height Adjustment Arm ASM
8:2	70-9760	1	Bushing
8:3	47-2900	1	Bushing
8:4	302-56	1	Fitting-Grease
9	92-1008	2	Knob-Lever, Height Adjustment
10	614447	2	Spacer-Axle Shaft
11	32144-85	2	Screw-HWH
12	92-1004	2	Rear Spring Arm ASM
13	603773	2	Nut
14	65-4730	2	Washer-Arm, Pivot
15	65-4760	2	Washer-Clutch
16	65-4750	2	Gear-Pinion
17	65-4720	2	Spring-Compression
18	94-1609	2	Cover-Wheel
19	614426	2	Washer-Stepped

Ref	Part No.	Qty.	Description
20	93-7381	1	V-Belt



Engine and Blade Assembly

Ref	Part No.	Qty.	Description				
1	105-8579	1	Bolt-Blade				
2	612543-03	1	Blade				
3	92-1024-03	1	Guide-Belt				
4	104-7955	1	Decal-Deck				
5	106-8346-03	1	Guard-Muffler				
7	32144-85	1	Screw-HWH				
8	98-1593	1	Applique				
9	106-8375	1	Decal-Recoil				
10	92-1701	1	Stop-Rope				
11		1	Engine-Tecumseh, Lv195ea-362005b				
12	93-4196-03	1	Shield-Glass				
13	95-1726	3	Screw-Taptite				
14	106-3950	1	Driver-Blade				
15	106-6826	1	Spacer				




Handle Assembly

Ref	Part No.	Qty.	Description				
1	104-1013	1	Guard-Cable				
2	614643-05	1	Handle-Lower				
3	100-5989	1	Brake Cable ASM				
4	106-8330	1	Guide-Rope				
6	100-2888-05	1	Handle-Upper				
7	107-0757	2	Stop-Pivot				
8	93-4184-03	1	Bail-Brake				
10	92-1001-03	1	Bail-Control				
11	3296-73	2	Nut-Lock, NI				
12	3256-1	1	Washer-Flat				
13	100-5982	1	Cable-Ground Speed				
14	92-7729	1	Anchor-Cable, Upper				
15	92-2266	1	Screw-Handle				
16	106-4161	2	Knob-Handle				
17	614697	2	Screw				
18	93-7380	1	Anchor-Cable				

Engine Assembly No. 1

Tecumseh Model No. LV195EA-362005B



Engine Assembly No. 1


Tecumseh Model No. LV195EA-362005B

Ref	Part No.	Qty.	Description
④1	37465	1	Cylinder(Incl. Ref. #2, 20 And 150)
④2	26727	2	Pin-Dowel
④6	33734	1	Element-Breather
④7	36557	1	Breather ASM (Incl. Ref. #6 And 12a)
④12	36775	1	Tube-Breather
④12A	36558	1	Breather Cover And Tube (Incl. Ref. #12b)
④12B	36694	1	Elbow-Tube, Breather
④14	28277	1	Washer
④15	30589	1	Governor Rod (Incl. Ref. #14)
④16	34839A	1	Lever-Governor
④17	31335	1	Clamp-Governor Lever
④18	651018	1	Screw, T-15, 8-32 X 19/64in
④19	36281	1	Spring-Extension
④20	32600	1	Seal-Oil
④30	37692	1	Crankshaft
④40	40027	1	Piston, Pin And Ring Set (Std.)
④41	40042	1	Piston And Pin ASM (Std.) (Incl. Ref. #43)
④42	40006	1	Ring Set (Std.)
④43	20381	2	Retaining Ring-Piston Pin
④45	36777	1	Connecting Rod ASM (Incl. Ref. #46)
④46	32610A	2	Bolt-Connecting Rod
④48	27241	2	Lifter-Valve
④50	37460	1	Camshaft (Exhaust Mcr) (Incl. Ref. #104)
④52	29914	1	Oil Pump ASM
④569	37609	1	Gasket-Mounting Flange
④70	37608	1	Mounting Flange (Incl. Ref. #72-83, 306, 309a And 311a)
④72	37614	1	Plug-Oil Drain
④75	27897	1	Seal-Oil
④80	30574A	1	Shaft-Governor
④81	30590A	1	Washer
④82	30591	1	Governor Gear ASM (Incl. Ref. #81)
④83	30588A	1	Spool-Governor
④86	650488	6	Screw, 1/4-20 X 1-1/4in
④89	611298	1	Key-Flywheel
④90	611299	1	Flywheel
④92	650815	1	Washer-Belleville
④93	650816	1	Nut-Flywheel
④100	34443C	1	Ignition-Solid State
④101	610118	1	Cover-Spark Plug
④103	651007	2	Screw, T-15, 10-24 X 15/16in
④104	37480	1	Bushing-Cam
④110	37047	1	Wire-Ground
④5119	37796	1	Gasket-Cylinder Head
④120	37714	1	Sprocket Assembly
④125	36780	1	Exhaust Valve (1/32" Os) (Incl. Ref. #151)

Ref	Part No.	Qty.	Description
④125	37288	1	Exhaust Valve (Std.) (Incl. Ref. #151)
④126	37289	1	Intake Valve (Std.) (Incl. Ref. #151and 151a)
④130	6021A	8	Screw, 5/16-18 X 1-7/16in
④135	35395	1	Resistor-Spark Plug (Rj19lm)
④150	31672	2	Spring-Valve
④151	31673	2	Cap-Valve Spring
④151A	40017	1	Seal-Intake Valve
④166	37813	1	Engine Shroud (Green)
④5169	36783	1	Gasket-Valve Cover
④172	36784	1	Cover-Valve
④174	30200	2	Screw, 10-24 X 9/16in
④178	29752	2	Nut And Lock Washer, 1/4-28
④182	6201	2	Screw, 1/4-28 X 7/8in
④5184	26756	1	Gasket-Carburetor To Intake Pipe
④185	37466	1	Pipe-Intake
④186	32653	1	Link-Governor
④189	650839	2	Screw, 1/4-20 X 3/8in
④191	36559A	1	S.e. Brake Bracket (Incl. Ref. #195)
④195	610973	1	Terminal
④207	34336A	1	Link-Throttle
④216	33086	1	Lever-R.p.m. Adjusting
④223	650451	2	Screw, 1/4-20 X 1in
④5224	36786	1	Gasket-Intake Pipe
④238	650932	2	Screw, 10-32 X 49/64in
④5239	34338	1	Gasket-Air Cleaner
④241	36919	1	Collar-Air Cleaner
④245	36905	1	Filter-Air Cleaner
④250	37122	1	Cover-Air Cleaner
④260	37696A	1	Housing-Blower
④261	30200	2	Screw, 10-24 X 9/16in
④262	650831	2	Screw, 1/4-20 X 1/2in
④275	37498	1	Muffler
④277	650988	2	Screw, 1/4-20 X 2-9/32in
④285	35000A	1	Cup-Starter
④287	650926	2	Screw, 8-32 X 21/64in
④290	29774	1	Line-Fuel
④292	26460	2	Clamp-Fuel Line
④298	28763	2	Screw

Engine Assembly No. 2


Tecumseh Model No. LV195EA-362005B



Engine Assembly No. 2

Tecumseh Model No. LV195EA-362005B


Ref	Part No.	Qty.	Description				
④300	37947	1	Fuel Tank (Incl. Ref. #292 And 301)				
④301	37844	1	Fuel Cap ASM				
④305	35647	1	Tube-Oil Fill				
④⑤306	37610	1	O-Ring				
④307	35499	1	O-Ring				
④309	650562	1	Screw, 10-32 X 1/2in				
④309A	650783	1	Screw, 10-24 X 3/4in				
④310	35648	1	Dipstick				
④311A	37611	1	Bracket-Hold Down				
④313	34080	1	Spacer				
④347	650898A	1	Screw, 10-32 X 27/32in				
④370A	36261	2	Decal-Lubrication				
④370C	37695	1	Decal-Primer (3 X)				
④370D	35977	1	Decal-Warning				
④380	640303	1	Carburetor (Incl. Ref. #184)				
④390	590739	1	Starter-Rewind				
④400	37613	1	Gasket Set (Incl. Items Marked Pk In Notes)				
④416	37530	1	Kit-Spark Arrestor (Optional)				
④	750876	1	Short Block Asm				



Carburetor Assembly No. 640303 Tecumseh Model No. LV195EA-362005B


Ref	Part No.	Qty.	Description
④0	640303	1	Carburetor (Incl. Ref. #184 Of Engine Parts List)
④1	631615	1	Throttle Shaft And Lever ASM
④2	631767	1	Spring-Throttle Return
③④4	631184	1	Washer-Dust Seal
③④5	631183	1	Dust Seal
④6	640070	1	Shutter-Throttle
③④7	650506	1	Screw-Shutter
④16	631807	1	Fitting-Fuel
④17	651025	1	Throttle Crack Screw/Idle Speedscrew
④18	630766	1	Spring-Tension
④20	640018	1	Screw-Idle Restrictor
③④20A	640200	1	Cap-Idle Restrictor Screw
④25	631867	1	Bowl-Float
③④27	631024	1	Shaft-Float
④28	632802	1	Float (Plastic)
③④29	631028	1	O-Ring-Float Bowl
③④30	632807	1	Inlet Needle, Seat, And Clip (Incl. Ref. #31)
③④31	631022	1	Clip-Spring
④35	640259	1	Retainer Ring-Primerbulb (Red)
④36	640019	1	Tube-Main Nozzle
④36A	632766	1	Extension-Bowl Vent Tube
③④37	632547	2	O-Ring-Main Nozzle Tube

Ref	Part No.	Qty.	Description
④40	640087	1	High Speed Bowl Nut
③④44	27110A	1	Washer-Bowl Nut
③④47	630748	1	Welch Plug-Idle Mixture Well
③④48	631027	2	Welch Plug-Atmospheric Vent
③④60	632809	1	Repair Kit



Recoil Starter Assembly No. 590739 Tecumseh Model No. LV195EA-362005B

Ref	Part No.	Qty.	Description				
0	590739	0	Starter-Rewind				
3	590740	1	Retainer				
6	590616	2	Dog-Starter				
7	590617	2	Spring-Dog				
8	590618A	1	Pulley And Rewind Spring ASM				
11	590638	1	Housing Assembly-Starter				
12	590535	1	Rope-Starter (Length 98in X 9/64in Dia.)				
13	590701	1	Handle-Starter				
14	590760	1	Spring Clip				



Recoil Starter Assembly No. 590702 (Optional) Tecumseh Model No. LV195EA-362005B

Ref	Part No.	Qty.	Description				
0	590702	0	Starter-Recoil				
1	590599A	1	Spring Pin (Incl. Ref. #4)				
2	590600	1	Washer				
3	590696	1	Retainer				
4	590601	1	Washer				
5	590697	1	Spring-Brake				
6	590698	2	Dog-Starter				
7	590699	2	Spring-Dog				
8	590700	1	Pulley & Rewind Spring ASM				
11	590703A	1	Starter Housing ASM (40 Degree Grommet)				
12	590535	1	Rope-Starter (Length 98in X 9/64in Dia.)				
13	590701	1	Handle-Starter				

NOTES

LAWN-BOY®