

LAWN-BOY®

21" GOLD SERIES WALK-BEHIND MOWER

HAND PUSH

MODEL NO.10415-4900001 & UP

MODEL NO.10420-4900001 & UP

SELF PROPELLED

MODEL NO.10515-4900001 & UP

MODEL NO.10520-4900001 & UP

PARTS CATALOG

PRODUCT CHANGES

In an effort to make improvements available to LAWN-BOY owners as quickly as possible, minor changes are incorporated into LAWN-BOY products from time to time that do not become immediately shown in the Parts Catalog. If such a change has been made in your unit, which is not reflected in your Parts Catalog, see your LAWN-BOY Distributor or his Authorized LAWN-BOY Service Dealer for information and part numbers.

IDENTIFICATION AND ORDERING

MODEL AND SERIAL NUMBERS

The Product has two identification numbers; a model number and a serial number. The two numbers are stamped on a plate mounted on the back side of the control panel. In any correspondence concerning the Product, supply model and serial numbers to assure that correct information and replacement parts are obtained.

To order replacement parts from an Authorized Service Dealer, supply the following information:

1. Model and serial number.
2. Part number, description, and the quantity of part(s) desired.


NOTE: Do not order by reference number if a parts catalog is being used; use the PART NUMBER.

TABLE OF CONTENTS

Description	Page	Description	Page
2 Cycle Engine, Fuel Tank And		Gear Case Assembly	5
Blade Assembly	1	Handle Assembly	6
Deck And Wheel Assembly (Hand Push)		Rear Grass Catcher Assembly	7
Model No. 10415 & 10420	2	Engine Assembly	8
Deck And Wheel Assembly (Self Propelled)		Starter Assembly (Pull)	10
Model No.10515 & 10520	3	Carburetor Assembly	11
Rear Axle Assembly		Lawn-Boy Numeric Index	12
Model No..10515 & 10520	4		

Accessories

Description	Model / Parts No.	Description	Model / Parts No.
Cover Plate, Mulch	92-8630 or 89864	Grass Bag	89816
Cover Plate, Side Discharge	607560	must use Side Chute Attachment.	
Rear Catcher Assembly	89800	Note:	
Side Catcher Assembly	89814	Models No. 10420 and 10520 Include Rear Grass	
Side Chute Attachment	89852	Catcher Assembly Model No. 89800 as standard	
Leaf Shredder Attachment	89860	equipment	
Replacement Bags			
Leaf Bag	89818		
must use Side Chute Attachment.			




ENGINE, FUEL TANK & BLADE ASSEMBLY

C-1324

Ref. No.	Part No.	Description	No. Used
1	306531	Nut	1
2	611213	Retainer	1
3	611509	Actuator - Lever Brake	1
4	611214	Spring	1
5	16-5539	Shroud & Tank Assembly	1
6	684301	Base - Starter	1
7	683896	Starter Assembly	1
8	611395	Screw - Self Tapping	4
9	612428	Screw	4
10	47-2480	Stop - Rope	1
11	611327	Cap - Fuel	1
12	607213	Gasket - Fuel Cap	1
13	609150	Baffle Fuel Cap	1
14	605120	Grommet	1
15	92-7879	Decal - Recoil (Hand Push)	1
*	92-7880	Decal - Recoil (Self Propelled).	1
16		Engine Assembly	1

Ref. No.	Part No.	Description	No. Used
17	612783	Line - Fuel	1
18	612974	Screen - Fuel Line	1
19	314576	Screw	1
20	677525	Plate & Collar Assembly	1
21	612543	Blade 21"	1
22	92-1630	Fan - Mulching	1
23	603164	Nut - Blade	1
24	92-1648	Screw - Engine	3
25	682876	Muffler Cover Assembly	1
26	609786	Support - Crankshaft	1
27	609471	Screw	3
28	92-1054	Plate - Muffler	1
29	613500	Screw	1
30	607601	Screw	3
31	609420	Gasket - Muffler	1
32	610345	Screw - Set	1
33	609976	Pulley	1
34	32144-53	Screw - Self Tapping	1

* Not Illustrated




C-1325

DECK AND WHEEL ASSEMBLY (Hand Push)

Ref. No.	Part No.	Description	No. Used
1	604604	Grommet	3
2	614677	Screw – Thread Forming	2
3	614682	Knob	1
4	92-8630	Cover – Plate, Mulch	1
*	607560	Cover – Side Discharge	1
5	39-5770	Decal – Danger (English)	1
8	92-5429	Decal – Danger (French /English)	1
6	610358	Nut	2
7	92-9673	Bolt – Shoulder	2
8	92-7736	Shield – Trailing	1
11	92-5791	Spacer	2
12	92-1005	Spring Arm Assembly	2
13	3290-413	Washer – Belleville	4
14	92-4856	Bolt – Shoulder	2
15	92-1604	Hub Cap	4

Ref. No.	Part No.	Description	No. Used
16	614650	Bolt – Wheel	2
17	684777	Wheel Assembly 8"	2
18	40-1940	Washer – Wheel Bolt	6
19	614637	Bracket – H. O. C.	4
20	706213	Washer	2
21	608834	Washer	2
23	92-1008	Knob – Spring Arm	4
24	92-1006	Spring Arm Assembly	2
25	684776	Wheel – 6"	2
26	92-1099	Bolt – Wheel	2
28	46-6811	Screw	2
29	608175	Bar – Toe	1
30	614701	Applique	1
31	16-5769	Housing – 21" (Incl. Ref.#5 & 30)	1
32	3296-39	Nut – Lock	4

* Not Illustrated




C-1326

DECK AND WHEEL ASSEMBLY (Self Propelled)

Ref. No.	Part No.	Description	No. Used
1	604604	Grommet	3
2	614677	Screw - Thread Forming	2
3	614682	Knob	1
4	92-8630	Cover - Plate, Mulch	1
*	607560	Cover - Side Discharge	1
5	39-5770	Decal - Danger (English)	1
*	92-5429	Decal - Danger (French/English)	1
6	610358	Nut	2
7	40-1940	Washer - Wheel Bolt	6
8	92-9673	Bolt - Shoulder	2
9	926641	Screw	2
10	92-8852	Cover - Drive	1
11	92-7748	Screw	2
12	92-7699	Bracket - Actuator	1
13	256-251	Bushing	2

Ref. No.	Part No.	Description	No. Used
14	92-7869	Gear Case Assembly	1
15	92-7736	Shield - Trailing	1
19	92-1008	Knob - Spring Arm	4
20	92-1006	Spring Arm Assembly	2
21	3290-413	Washer - Belleville	2
22	92-4856	Bolt - Shoulder	2
23	684776	Wheel - 6"	2
24	92-1099	Bolt - Wheel	2
25	92-1604	Hub Cap	4
27	614637	Bracket - H. O. C.	2
29	46-6811	Screw	2
30	608175	Bar - Toe	1
31	614701	Applique	1
32	16-5779	Housing - 21 (Incl. Ref. #5 & 31)	1
33	3296-39	Nut - Lock	2

*Not Illustrated




REAR WHEEL DRIVE ASSEMBLY

Ref. No.	Part No.	Description	No. Used
1	92-1008	Knob - Spring Arm (Ref.)	2
2	92-6540	Spring Arm Assembly L.H.	2
*	92-6539	Spring Arm Assembly R.H.	2
3	70-9760	Bushing	2
4	92-7746	Pivot Arm Assembly	2
5	614442	Fitting - Grease (Ref.)	2
6	47-2900	Bushing	2
7	65-4730	Washer - Thrust	2
8	65-4740	Washer - Thrust	4
9	65-4710	Ring - Friction	2
10	65-4760	Washer - Clutch	2
11	66-6050	Key - Rocking, L.H.	1
*	66-6040	Key - Rocking, R.H.	1
12	65-4750	Gear - Pinion	2
13	614426	Washer - Stepped	2
14	92-1042	Wheel - 8"	2

Ref. No.	Part No.	Description	No. Used
15	92-1057	Bolt - Wheel	2
16	614427	Cover - Wheel	2
17	65-2720	Ring - Retaining	4
18	65-4720	Spring - Compression	2
19	32144-70	Screw - Hex. Hd.	1
20	82-8780	Retainer - Cable	1
21	60-8821	Lever - Shift	1
23	3272-10	Pin - Cotter	1
24	610358	Nut	2
25	32144-85	Screw	2
27	92-6535	Cap - End	2
28	92-1043	"V" Belt	1
29	605255	Washer - Felt	1
30	303259	Washer - Flat	1
31	24-7920	Cover - Drive Shaft	1

*Not Illustrated




C-1322

GEAR CASE ASSEMBLY

Ref. No.	Part No.	Description	No. Used
1	32121-120	Pin - Coil	1
2	38-7820	Bearing - Ball	1
3	60-8850	Bushing - Output	1
4	65-4770	Shaft - Output	1
5	92-5791	Spacer	1
6	60-8840	Pulley - Half	2
7	3296-5	Nut	1
8	3256-24	Washer	1
9	60-8710	Gearcase - Upper	1
10	60-8870	Yoke - Shift	1
11	29-9570	Bushing - Yoke	1
12	60-8810	Retainer - Shift Fork	1
13	76-0780	Sleeve - Shift Key	1
14	76-0760	Key - Shift	2
15	76-0770	Collar - Shift	1
16	65-5250	Clip - Spring	1

Ref. No.	Part No.	Description	No. Used
17	36-4780	Washer	1
18	60-8770	Bushing - Output	1
19	60-8750	Bushing - Inter. Shaft	2
20	36-4791	Washer - Thrust	2
21	49-2040	Screw	6
22	60-8730	Gear Case Cover	1
23	55-3760	Pinion - 15 Tooth	1
24	55-3780	Pinion - 20 Tooth	1
25	55-3800	Pinion - 25 Tooth	1
26	60-8800	Shaft - Intermediate	1
27	92-5790	Pinion - Bevel	1
28	55-3770	Gear - 49 Tooth	1
29	55-3790	Gear - 44 Tooth	1
30	55-3810	Gear - 39 Tooth	1
31	60-8790	Sleeve - Gear	1




C-1327

HANDLE ASSEMBLY

Ref. No.	Part No.	Description	No. Used
1	92-7720	Guide - Rope	1
2	321-51	Bolt	1
3	92-2268	Screw	1
4	612825	Handle - Rope	1
5	92-2918	Decal - Control Panel	1
6	92-1633	Cable - Brake	1
7	16-2049	Panel - Control (Self Propelled Incl. Ref.#10 & 11)	1
*	16-2039	Panel - Control (Hand Push Incl. Ref. #10 & 11)	1
8	92-1093	Bail - Brake	1
9	92-8926	Control Ground Speed (Self Propelled)	1
10	92-2940	Decal - Warning (English)	1
8	92-5427	Decal - Warning (French/English)	1
11	92-1623	Decal - Control Panel (Self Propelled English)	1
8	92-5426	Decal - Control Panel Hand Push French/English)	1
*	92-2902	Decal - Control Panel (Hand Push English)	1
8	92-5430	Decal - Control Panel	1

Ref. No.	Part No.	Description	No. Used
12	92-1643	(Hand Push French/English) Control - Throttle	1
13	92-9665	Screw	4
14	612824	Insert - Handle	1
15	92-1617	Bail - Control (Self Prop.)	1
16	92-5412	Stop - Pivot (Self Prop.)	1
17	3296-73	Nut	3
18	92-1094	Bracket - Cam	1
19	92-1078	Brake - BBC Cam	1
20	614697	Screw - Handle	2
21	92-1092	Handle - Upper	1
22	614243	Knob - Handle	2
23	613050	Bolt - Shoulder	1
24	321-4	Screw - Hex. Hd.	1
25	614249	Tie - Cable	2
26	3230-29	Bolt - Carriage	2
27	92-6537	Handle - Lower	1
28	92-7899	Bracket - Traction Cable (Self Propelled)	1
29	92-6518	Cable - Traction (Self Propelled)	1
30	3253-33	Washer	2
31	32103-29	Nut - Wing	2
32	92-2928	Bracket - Cable	1

*Not Illustrated




REAR CATCHER ASSEMBLY

Ref. No.	Part No.	Description	No. Used
1	684729	Chute & Support Assembly (Incl. Ref.# 2,3 & 9)	1
2	614589	Nut - Cap	1
3	614591	Chute Support	1
4	684727	Adaptor Assembly	1
5	614700	Tie Strap	1

Ref. No.	Part No.	Description	No. Used
6	*	Bag Assembly	1
7	613462	Hanger Clamp	2
8	613455	Wide Hanger	1
9	92-2919	Decal - Danger	1

*Includes Ref.#5 and instruction sheet for installing bag to adapter assembly. Order via model #89810.

ENGINE ASSEMBLY




ENGINE ASSEMBLY

Ref. No.	Part No.	Description	No. Used
1	611213	Retainer	1
2	611509	Actuator – Brake Lever	1
3	611214	Spring – Cable, Return	1
4	683968	Switch Assembly (Incl. Ref. #1,6,20, & 56-58)	1
5	682683	Brake Assembly	1
6	92-1633	Wire Lead	1
7	613529	Bolt – Shoulder	1
8	608311	Nut	1
9	683581	Brace Assembly	1
10	603014	Bolt	1
11	603093	Washer	1
12	602315	Nut	1
13	612427	Shroud – Base	1
14	611191	"J" Clip	1
15	609947	Screw	3
16	683580	Flywheel Assembly	1
17	316959	Washer – Lock	1
18	130743	Nut – Flywheel	1
19	609808	Screw	2
20	317893	Tie Strap	1
21	681737	Set – Ring	1
22	303712	Ring – Retaining	2
23	606608	Pin – Wrist	1
24	92-4924	Piston	1
*	92-4923	Set – Piston & Ring (Incl. Ref.# 21-24)	1
*	92-4937	Piston & Connecting Rod Assembly (Incl. Ref. # 21-27, 32 & 33)	1
25	92-4927	Bearing Assembly	1
26	92-4921	Connecting Rod Assembly (Incl. Ref. #25, 27,32 & 33)	1
27	677982	Liner – Pair	1
28	607199	Key – Flywheel	1

Ref. No.	Part No.	Description	No. Used
29	611396	Seal – Oil	1
30	681830	Bearing – Main	1
31	92-6375	Crankshaft	1
32	611393	Screw	2
33	683911	Set – Needle Bearing	1
34	607526	Screw	2
35	614009	Spark Plug	1
36	683080	Cover – Terminal	1
37	681678	Wire Lead & Cover Assy. (Incl. Ref. # 36)	1
38	683215	C. D. Ignition Module (Incl. Ref. #36, 37)	1
39	605120	Grommet	2
40	614249	Tie Strap	1
41	613073	Bracket – C. D.	1
42	614343	Screw	2
43	683702	Cylinder & Crankcase Cover Assembly (Incl. Ref. # 46-48,51 & 53)	1
44	609123	Plug	4
45	609420	Gasket – Exhaust	1
46	612872	Screw	2
47	602587	Plate – Reed	1
48	602588	Reed	1
49	681831	Bearing – Main	1
50	611396	Seal – Oil	1
51	613110	Screw	2
52	611192	Bracket – Brake	1
53	613233	Screw	2
54	611211	Spring – Brake	1
55	683819	Case Assembly	1
56	306407	Washer	1
57	609891	Screw	1
*	92-6353	Short Block	1

*Not Illustrated




C-1337

STARTER

Ref. No.	Part No.	Description	No. Used
*	683896	Starter Assembly (Incl. Ref. #5-9)	1
1	92-1645	Decal - Recoil (Hand Push)	1
*	92-1644	Decal - Recoil (Self Propelled)	1
2	684567	Starter Housing & Shaft	1

Ref. No.	Part No.	Description	No. Used
3	683897	Spring & Keeper	1
4	612825	Handle - Starter	1
5	612824	Clip - Rope	1
6	612432	Rope	1
7	612950	Pulley	1
8	612949	Hub - Starter	1
9	683899	Kit - Dog	1



C-1340

CARBURETOR ASSEMBLY 684256

Ref. No.	Part No.	Description	No. Used
*	684352	Body - Carburetor (Incl. Ref. #18-34)	1
1	612505	Vane - Air	1
2	92-6392	Screw	1
3	610165	Retainer - Speed Control Lever	1
4	612502	Lever - Governor Control	1
5	612757	Collar	1
6	613142	Spring	1
7	308052	Washer	1
8	612504	Base - Air Filter	1
9	612503	Spacer - Filter Base	1
10	609493	Element - Air Filter	1
11	611377	Cover - Air Filter	1
12	610383	Retainer - Cover	1
13	328712	Nut	1
14	314576	Screw	1
15	612974	Filter - Fuel	1
16	92-4947	Shield - Heat	1
17	612507	Screw	2
*	612783	Line - Fuel	1
*	684286	Kit - Throttle (Incl. Ref. #18-20)	1
18		Shaft - Throttle	1
19		Vane - Throttle	1
20		Screw	1

Ref. No.	Part No.	Description	No. Used
*	684285	Kit - Idle Needle	1
21		Spring - Needle	1
22		Needle - Idle	1
23	683783	Kit - Float Assembly	1
*	683782	Kit - Bowl (Incl. Ref. #24-25)	1
24		Bowl - Fuel	1
25		Screw	1
*		Kit - Gasket	1
*	683778	Kit - Gasket (Incl. Ref. #26 & 27)	1
26		Gasket - Bowl Retainer	1
27		Gasket - Bowl	1
*	683777	Kit - Repair (Incl. Ref. #28-31)	1
28		Plug - Welch	2
29		Shaft - Float	1
30		Inlet - Needle Valve	1
31		Seat - Valve	1
*		Kit - Gasket	1
*	683781	Kit - Choke (Incl. Ref. #32-34)	1
32		Valve - Choke	1
33		Spring - Return	1
34		Shaft - Choke	1
35	612574	Gasket Carburetor	2

LAWN-BOY PART NUMBER INDEX

3316-588

Part No.	Description	Pg. Ref. No. No. Qty.	Part No.	Description	Pg. Ref. No. No. Qty.
*	Bag Assembly	7 6 1	611393	Screw	9 32 2
130743	Nut - Flywheel	9 18 1	611395	Screw - Self Tapping	1 8 4
303259	Washer - Flat	4 30 1	611396	Seal - Oil	9 29 1
303712	Ring - Retaining	9 22 2	611396	Seal - Oil	9 50 1
306407	Washer	9 56 1	611509	Actuator - Brake Lever	9 2 1
306531	Nut	1 1 1	611509	Actuator - Lever Brake	1 3 1
308052	Washer	11 7 1	612427	Shroud - Base	9 13 1
314576	Screw	11 14 1	612428	Screw	1 9 4
314576	Screw	1 19 1	612432	Rope	10 6 1
316959	Washer - Lock	9 17 1	612502	Lever - Governor Control	11 4 1
317893	Tie Strap	9 20 1	612503	Spacer - Filter Base	11 9 1
328712	Nut	11 13 1	612504	Base - Air Filter	11 8 1
602315	Nut	9 12 1	612505	Vane - Air	11 1 1
602587	Plate - Reed	9 47 1	612507	Screw	11 17 2
602588	Reed	9 48 1	612543	Blade 21"	1 21 1
603014	Bolt	9 10 1	612574	Gasket Carburetor	11 35 2
603093	Washer	9 11 1	612757	Collar	11 5 1
603164	Nut - Blade	1 23 1	612783	Line - Fuel	11 * 1
604604	Grommet	2 1 3	612783	Line - Fuel	1 17 1
604604	Grommet	3 1 3	612824	Clip - Rope	10 5 1
605120	Grommet	1 14 1	612824	Insert - Handle	6 14 1
605120	Grommet	9 39 2	612825	Handle - Rope	6 4 1
605255	Washer - Felt	4 29 1	612825	Handle - Starter	10 4 1
606608	Pin - Wrist	9 23 1	612872	Screw	9 46 2
607199	Key - Flywheel	9 28 1	612949	Hub - Starter	10 8 1
607213	Gasket - Fuel Cap	1 12 1	612950	Pulley	10 7 1
607526	Screw	9 34 2	612974	Filter - Fuel	11 15 1
607560	Cover - Side Discharge	2 * 1	612974	Screen - Fuel Line	1 18 1
607560	Cover - Side Discharge	3 * 1	613050	Bolt - Shoulder	6 23 1
607601	Screw	1 30 3	613073	Bracket - C. D.	9 41 1
608175	Bar - Toe	2 29 1	613110	Screw	9 51 2
608175	Bar - Toe	3 30 1	613142	Spring	11 6 1
608311	Nut	9 8 1	613233	Screw	9 53 2
608834	Washer	2 21 2	613455	Wide Hanger	7 8 1
609123	Plug	9 44 4	613462	Hanger Clamp	7 7 2
609150	Baffle Fuel Cap	1 13 1	613500	Screw	1 29 1
609420	Gasket - Exhaust	9 45 1	613529	Bolt - Shoulder	9 7 1
609420	Gasket - Muffler	1 31 1	614009	Spark Plug	9 35 1
609471	Screw	1 27 3	614243	Knob - Handle	6 22 2
609493	Element - Air Filter	11 10 1	614249	Tie - Cable	6 25 2
609786	Support - Crankshaft	1 26 1	614249	Tie Strap	9 40 1
609808	Screw	9 19 2	614343	Screw	9 42 2
609891	Screw	9 57 1	614426	Washer - Stepped	4 13 2
609947	Screw	9 15 3	614427	Cover - Wheel	4 16 2
609976	Pulley	1 33 1	614442	Fitting - Grease (Ref.)	4 5 2
610165	Retainer - Speed	11 3 1	614589	Nut - Cap	7 2 1
610345	Screw - Set	1 32 1	614591	Chute Support	7 3 1
610358	Nut	2 6 2	614637	Bracket - H. O. C.	2 19 4
610358	Nut	3 6 2	614637	Bracket - H. O. C.	3 27 2
610358	Nut	4 24 2	614650	Bolt - Wheel	2 16 2
610383	Retainer - Cover	11 12 1	614677	Screw - Thread Forming	2 2 2
611191	JClip	9 14 1	614677	Screw - Thread Forming	3 2 2
611192	Bracket - Brake	9 52 1	614682	Knob	2 3 1
611211	Spring - Brake	9 54 1	614682	Knob	3 3 1
611213	Retainer	9 1 1	614697	Screw - Handle	6 20 2
611213	Retainer	1 2 1	614700	Tie Strap	7 5 1
611214	Spring	1 4 1	614701	Applique	2 30 1
611214	Spring - Cable, Return	9 3 1	614701	Applique	3 31 1
611327	Cap - Fuel	1 11 1	677525	Plate & Collar Assembly	1 20 1
611377	Cover - Air Filter	11 11 1	677982	Liner - Pair	9 27 1

*Not Illustrated

LAWN-BOY PART NUMBER INDEX (Cont.)

3316-588

Part No.	Description	Pg. No.	Ref. No.	Qty.	Part No.	Description	Pg. No.	Ref. No.	Qty.
681678	Wire Lead & Cover Assy.	9	37	1	60-8710	Gearcase - Upper	5	9	1
681737	Set - Ring	9	21	1	60-8730	Gear Case Cover	5	22	1
681830	Bearing - Main	9	30	1	60-8750	Bushing - Inter. Shaft	5	19	2
681831	Bearing - Main	9	49	1	60-8770	Bushing - Output	5	18	1
682683	Brake Assembly	9	5	1	60-8790	Sleeve - Gear	5	31	1
682876	Muffler Cover Assembly	1	25	1	60-8800	Shaft - Intermediate	5	26	1
683080	Cover - Terminal	9	36	1	60-8810	Retainer - Shift Fork	5	12	1
683215	C. D. Ignition Module	9	38	1	60-8821	Lever - Shift	4	21	1
683580	Flywheel Assembly	9	16	1	60-8840	Pulley - Half	5	6	2
683581	Brace Assembly	9	9	1	60-8850	Bushing - Output	5	3	1
683702	Cylinder & Crankcase Cover	9	43	1	60-8870	Yoke - Shift	5	10	1
683777	Kit - Repair	11	*	1	65-2720	Ring - Retaining	4	17	4
683778	Kit - Gasket	11	*	1	65-4710	Ring - Friction	4	9	2
683781	Kit - Choke	11	*	1	65-4720	Spring - Compression	4	18	2
683782	Kit - Bowl	11	*	1	65-4730	Washer - Thrust	4	7	2
683783	Kit - Float Assembly	11	23	1	65-4740	Washer - Thrust	4	8	4
683819	Case Assembly	9	55	1	65-4750	Gear - Pinion	4	12	2
683896	Starter Assembly	10	*	1	65-4760	Washer - Clutch	4	10	2
683896	Starter Assembly	1	7	1	65-4770	Shaft - Output	5	4	1
683897	Spring & Keeper	10	3	1	65-5250	Clip - Spring	5	16	1
683899	Kit - Dog	10	9	1	66-6040	Key - Rocking, R.H.	4	*	1
683911	Set - Needle Bearing	9	33	1	66-6050	Key - Rocking, L.H.	4	11	1
683968	Switch Assembly	9	4	1	70-9760	Bushing	4	3	2
684285	Kit - Idle Needle	11	*	1	76-0760	Key - Shift	5	14	2
684286	Kit - Throttle	11	*	1	76-0770	Collar - Shift	5	15	1
684301	Base - Starter	1	6	1	76-0780	Sleeve - Shift Key	5	13	1
684352	Body - Carburetor	11	*	1	82-8780	Retainer - Cable	4	20	1
684567	Starter Housing & Shaft	10	2	1	92-1005	Spring Arm Assembly	2	12	2
684727	Adaptor Assembly	7	4	1	92-1006	Spring Arm Assembly	3	20	2
684729	Chute & Support Assembly	7	1	1	92-1006	Spring Arm Assembly	2	24	2
684776	Wheel - 6"	3	23	2	92-1008	Knob - Spring Arm (Ref.)	4	1	2
684776	Wheel - 6"	2	25	2	92-1008	Knob - Spring Arm	3	19	4
684777	Wheel Assembly 8"	2	17	2	92-1008	Knob - Spring Arm	2	23	4
706213	Washer	2	20	2	92-1042	Wheel - 8"	4	14	2
926641	Screw	3	9	2	92-1043	"V" Belt	4	28	1
16-2039	Panel - Control	6	*	1	92-1054	Plate - Muffler	1	28	1
16-2049	Panel - Control	6	7	1	92-1057	Bolt - Wheel	4	15	2
16-5539	Shroud & Tank Assembly	1	5	1	92-1078	Brake - BBC Cam	6	19	1
16-5769	Housing - 21"	2	31	1	92-1092	Handle - Upper	6	21	1
16-5779	Housing - 21"	3	32	1	92-1093	Bail - Brake	6	8	1
24-7920	Cover - Drive Shaft	4	31	1	92-1094	Bracket - Cam	6	18	1
29-9570	Bushing - Yoke	5	11	1	92-1099	Bolt - Wheel	3	24	2
36-4780	Washer	5	17	1	92-1099	Bolt - Wheel	2	26	2
36-4791	Washer - Thrust	5	20	2	92-1604	Hub Cap	2	15	4
38-7820	Bearing - Ball	5	2	1	92-1604	Hub Cap	3	25	4
39-5770	Decal - Danger (English)	2	5	1	92-1617	Bail - Control (Self Prop.)	6	15	1
39-5770	Decal - Danger (English)	3	5	1	92-1623	Decal - Control Panel	6	11	1
40-1940	Washer - Wheel Bolt	3	7	6	92-1630	Fan - Mulching	1	22	1
40-1940	Washer - Wheel Bolt	2	18	6	92-1633	Cable - Brake	6	6	1
46-6811	Screw	2	28	2	92-1633	Wire Lead	9	6	1
46-6811	Screw	3	29	2	92-1643	Control - Throttle	6	12	1
47-2480	Stop - Rope	1	10	1	92-1644	Decal - Recoil	10	*	1
47-2900	Bushing	4	6	2	92-1645	Decal - Recoil	10	1	1
49-2040	Screw	5	21	6	92-1648	Screw - Engine	1	24	3
55-3760	Pinion - 15 Tooth	5	23	1	92-2268	Screw	6	3	1
55-3770	Gear - 49 Tooth	5	28	1	92-2902	Decal - Control Panel	6	*	1
55-3780	Pinion - 20 Tooth	5	24	1	92-2918	Decal - Control Panel	6	5	1
55-3790	Gear - 44 Tooth	5	29	1	92-2919	Decal - Danger	7	9	1
55-3800	Pinion - 25 Tooth	5	25	1	92-2928	Bracket - Cable	6	32	1
55-3810	Gear - 39 Tooth	5	30	1	92-2940	Decal - Warning (English)	6	10	1

*Not Illustrated

LAWN-BOY PART NUMBER INDEX (Cont.)

Part No.	Description	Pg. Ref. No. No. Qty.	Part No.	Description	Pg. Ref. No. No. Qty.
92-4856	Bolt - Shoulder	2 14 2	92-7748	Screw	3 11 2
92-4856	Bolt - Shoulder	3 22 2	92-7869	Gear Case Assembly	3 14 1
92-4921	Connecting Rod Assembly	9 26 1	92-7879	Decal - Recoil	1 15 1
92-4923	Set - Piston & Ring	9 24 1	92-7880	Decal - Recoil	1 * 1
92-4924	Piston	9 24 1	92-7899	Bracket - Traction Cable	6 28 1
92-4927	Bearing Assembly	9 25 1	92-8630	Cover - Plate, Mulch	2 4 1
92-4937	Piston & Connecting Rod	9 * 1	92-8630	Cover - Plate, Mulch	3 4 1
92-4947	Shield - Heat	11 16 1	92-8852	Cover - Drive	3 10 1
92-5412	Stop - Pivot (Self Prop.)	6 16 1	92-8926	Control Ground Speed	6 9 1
92-5426	Decal - Control Panel	6 * 1	92-9665	Screw	6 13 4
92-5427	Decal - Warning	6 * 1	92-9673	Bolt - Shoulder	2 7 2
92-5429	Decal - Danger	2 * 1	92-9673	Bolt - Shoulder	3 8 2
92-5429	Decal - Danger	3 * 1	256-251	Bushing	3 13 2
92-5430	Decal - Control Panel	6 * 1	321-4	Screw - Hex. Hd.	6 24 1
92-5790	Pinion - Bevel	5 27 1	321-51	Bolt	6 2 1
92-5791	Spacer	5 5 1	3230-29	Bolt - Carriage	6 26 2
92-5791	Spacer	2 11 2	3253-33	Washer	6 30 2
92-6353	Short Block	9 * 1	3256-24	Washer	5 8 1
92-6375	Crankshaft	9 31 1	3272-10	Pin - Cotter	4 23 1
92-6392	Screw	11 2 1	3290-413	Washer - Belleville	2 13 4
92-6518	Cable - Traction	6 29 1	3290-413	Washer - Belleville	3 21 2
92-6535	Cap - End	4 27 2	3296-5	Nut	5 7 1
92-6537	Handle - Lower	6 27 1	3296-39	Nut - Lock	2 32 4
92-6539	Spring Arm Assembly R.H.	4 * 2	3296-39	Nut - Lock	3 33 2
92-6540	Spring Arm Assembly L.H.	4 2 2	3296-73	Nut	6 17 3
92-7699	Bracket - Actuator	3 12 1	32103-29	Nut - Wing	6 31 2
92-7720	Guide - Rope	6 1 1	32121-120	Pin - Coil	5 1 1
92-7736	Shield - Trailing	2 8 1	32144-53	Screw - Self Tapping	1 34 1
92-7736	Shield - Trailing	3 15 1	32144-70	Screw - Hex. Hd.	4 19 1
92-7746	Pivot Arm Assembly	4 4 2	32144-85	Screw	4 25 2