

LAWN-BOY SERVICE MANUAL 1950-88 (Form 492-4608, Internet Revision)

Table of Contents – Page 1 of 3

[DEDICATION & OBJECTIVE](#)

[FOREWORD](#)

[SAFETY](#)

SECTION 1 - [MOWER HISTORY - TWO CYCLE THEORY](#)

SECTION 2 - [USING THIS MANUAL](#)

SECTION 3 - [ENGINE DIAGNOSIS - EXHAUST PORT CLEANING](#)

SECTION 4 - FUEL SYSTEM

[GENERAL \(4-1 TO 4-4\)](#)

[D-400 & D-600 SERIES ENGINES \(4-5 TO 4-28\)](#)

[F-SERIES ENGINES - GENERAL \(4-29 TO 4-33\)](#)

[F-SERIES CARBURETOR IDENTIFICATION \(4-34 TO 4-35\)](#)

[F-100 SERIES CARBURETOR - EARLY MODEL \(4-36 TO 4-37\)](#)

[F-100 & 300 SERIES CARBURETOR \(4-38 TO 4-41\)](#)

[F-100/200/300 SERIES REED VALVES \(4-42\)](#)

[F-100 & 300 SERIES FUEL SYSTEM TROUBLESHOOTING \(4-43\)](#)

[F-200 SERIES COMMERCIAL CARBURETOR \(METAL\) \(4-56 TO 4-60\)](#)

[F-200 SERIES FUEL SYSTEM TROUBLESHOOTING \(4-61\)](#)

SECTION 5 - GOVERNOR SYSTEM

[D-400 SERIES GOVERNOR \(5-1 TO 5-4\)](#)

[D-600 SERIES GOVERNOR \(5-5 TO 5-6\)](#)

[F-100 SERIES GOVERNOR \(4-44 TO 4-53\)](#)

[F-200 SERIES GOVERNOR \(4-62 TO 4-64\)](#)

[F-300 SERIES GOVERNOR \(4-54 TO 4-55\)](#)

SECTION 6 - IGNITION SYSTEM

[D-400 SERIES ENGINE \(6-1 TO 6-6, 6-15\)](#)

[D-600 SERIES ENGINE \(6-17 TO 6-23, 6-15\)](#)

[F- SERIES ENGINE \(6-7 TO 6-13, 6-23\)](#)

SECTION 7 - STARTER SYSTEM - MANUAL/ELECTRIC

[D-400 SERIES - MANUAL STARTER \(7-1 TO 7-3\)](#)

[D-600 SERIES - MANUAL STARTER \(7-4 TO 7-7, 7-9\)](#)

[D-400/600 SERIES - SELF-PROPEL STARTER INTERLOCK \(7-8\)](#)

[F-SERIES MANUAL SIDE MOUNT STARTER \(7-16 TO 7-19\)](#)

[F- SERIES SELF-PROPEL SIDE MOUNT STARTER INTERLOCK \(1978-82\) \(7-20 TO 7-23\)](#)

[D-400 SERIES - ELECTRIC STARTER \(7-10 TO 7-11\)](#)

[D-600 SERIES - ELECTRIC STARTER \(7-12\)](#)

[F-SERIES ELECTRIC STARTER \(7-13 TO 7-15, 7-24 TO 7-25\)](#)

LAWN-BOY SERVICE MANUAL 1950-88 (Form 492-4608, Internet Revision)

Table of Contents – Page 2 of 3

SECTION 8 - POWERHEAD

[D-400 SERIES - TEARDOWN/REASSEMBLY \(8-1 TO 8-9, 8-16 TO 8-24\)](#)

[\(NOTE - PAGE 8-9, ONLY TOP ½ IS D-400\)](#)

[D-600 SERIES - TEARDOWN/REASSEMBLY \(8-9 TO 8-15, 8-24\)](#)

[\(NOTE - PAGE 8-9, ONLY BOTTOM ½ IS D-600\)](#)

[F-SERIES TEARDOWN/REASSEMBLY \(8-24 TO 8-37\)](#)

SECTION 9 - ADJUSTMENTS, SAFETY FEATURES, BLADE, BLADE HOUSING

[ADJUSTMENTS \(NOT APPLICABLE TO ALL MODELS\) \(9-1 TO 9-7\)](#)

[SAFETY FEATURES \(NOT APPLICABLE TO ALL MODELS\) \(9-8 TO 9-11\)](#)

[BLADE AND BLADE HOUSING \(9-12 TO 9-18\)](#)

SECTION 10 - SELF-PROPELLED SERVICING

[C & D-400 SERIES CAPSTAN DRIVE - LOWER DRIVE BELT SYSTEM \(10-1 TO 10-6\)](#)

[C & D-400 SERIES CAPSTAN DRIVE - UPPER DRIVE BELT SYSTEM \(10-7 TO 10-13\)](#)

[D-600 SERIES CAPSTAN DRIVE \(10-14 TO 10-19\)](#)

[F-SERIES CAPSTAN DRIVE \(10-20 TO 10-32\)](#)

[UTILITY MODEL 8600, 8601 WITH D-SERIES ENGINE - CAPSTAN DRIVE \(10-33 TO 10-43\)](#)

[UTILITY & SCAMP MODELS 8602, 8603, 8604, 8605 WITH F-SERIES ENGINE - CAPSTAN DRIVE \(10-44 TO 10-53\)](#)

SECTION 11 - RIDING MOWERS

[CONTENTS \(11-i TO 11-vi\)](#)

[MODEL 9300 \(11-1 TO 11-16\)](#)

[MODEL 9301, 9302, 9302E, 9303E, 9600, 9601 \(11-17 TO 11-54\)](#)

[MODEL 9500, 9501 \(11-55 TO 11-79\)](#)

[MODEL 9266, 9328, 9328E, 9328ES, 9329S, 9329ES, 9368, 9368E, 9368ES, 9369ES \(11-80 TO 11-98\)](#)

SECTION 12 - SNOW BLOWERS

[CONTENTS \(12-1\)](#)

[MODEL 2650, 2650A, 2650B, 2680, 2680A, 2680B \(12-2 TO 12-11\)](#)

[MODEL 1840, 1840A \(12-12 TO 12-15\)](#)

[MODEL 1850 \(12-16 TO 12-21\)](#)

SECTION 13 - BATTERIES, ALTERNATORS, ELECTRIC MOWERS

[BATTERIES \(13-1 TO 13-18\)](#)

[ALTERNATORS \(13-19 TO 13-31\)](#)

[CORDLESS MOWER SERVICING \(13-32 TO 13-37\)](#)

[110 VOLT ELECTRIC MOWER MOTOR SERVICING \(13-38 TO 13-40\)](#)

SECTION 14 - [TOOLS & SPECIAL SERVICE ITEMS \(14-2 TO 14-18\)](#)

SECTION 15 - DEALER SECTION - AIDS AND SHOP HINTS (REMOVED, NO LONGER APPLICABLE)

LAWN-BOY SERVICE MANUAL 1950-88 (Form 492-4608, Internet Revision)

Table of Contents – Page 3 of 3

SECTION 16 - ENGINE & TORQUE SPECIFICATIONS

[QUICK REFERENCE CHART BY MODEL \(16-1 TO 16-18\)](#)

[QUICK REFERENCE CHART BY ENGINE \(16-19 TO 16-21\)](#)

[TORQUE SPECIFICATIONS \(16-22 TO 16-29\)](#)

[ENGINE SPECIFICATIONS/COMPARISON \(16-30 TO 16-32\)](#)

SECTION 17 - [C-SERIES ENGINE SERVICE \(17-1 TO 17-12\)](#)

SECTION 18 - GRASS TRIMMERS

[EDGER-TRIMMER SERVICE \(17-13\)](#)

[SPECIFICATIONS & TROUBLESHOOTING \(18-2 TO 18-5\)](#)

[MODEL 1300, 1330, 1360, 3100, 3130, 3160 \(18-6 TO 18-24\)](#)

[MODEL SSI, SSII, 1400, 1460 \(PISTON POWER PRODUCTS / RYOBI\) \(18-26 TO 18-54\)](#)

SECTION 19 - 1983/1984 CPSC SAFETY STANDARD COMPLIANT MOWERS

[MODEL LISTING \(19-1 TO 19-2\)](#)

[BLADE BRAKE CLUTCH \(BBC\) SERVICE \(19-7 TO 19-18\)](#)

[CD IGNITION, ALTERNATOR, CARBURETOR, PRIMER INFORMATION \(19-19 TO 19-20\)](#)

[STARTERS \(19-21 TO 19-26\)](#)

[ENGINE, BLADE & BLADE HOUSING INFORMATION \(19-27 TO 19-29\)](#)

[HOSE AND WIRE ROUTING \(19-32 TO 19-34\)](#)

[TROUBLESHOOTING \(19-35 TO 19-40\)](#)

[MODEL 4250, 4505, 8605 & LATER COMPLIANT MOWERS WITH CAPSTAN DR. \(19-41 TO 19-57, 19-60 TO 19-63\)](#)

SECTION 20 - [1984 MODEL 8125 SERVICE \(20-1 TO 20-23\)](#)